

PARTS CATALOG



2045 TRENDLINE
2060 OPTIMIZER

Covers from Frame No.
CAT 2.2 and CAT2,2T
2045-60 starting with frame no. 385

VER: 2.9

INDEX

INDEX

Symboler

1/2" Bulk.....	25
3/4" Bulk.....	25
3/4" Tredo Ring.....	25
3/8" Hydraulic hoses (1. lags Min: 250 bar.).....	95
20mm pin.....	19
30A Fuse.....	91
40A Fuse.....	91
2060 Filter complete.....	43
3/4" Hydraulic hoses (2. lags Min: 300 bar.).....	96

A

A/C Hose thick evaporator.....	58
A/C Hose thin evaporator.....	58
A/C House vers.2.....	59
Adjust screw.....	39
A-Frame Cat 1.....	27
Alu Rail Left Door.....	69
Alu Rail Right Door.....	69
Anchor Plate bolt.....	11

B

Ball Bar.....	33
Battery.....	91
Beacon flasher.....	90
Bearing.....	14
Bearing 25mm.....	19
Bearing 25mm Lift Cyl.....	24
Bearing 35mm.....	29
Bearing 45mm.....	29
Bearing complete.....	27
Bearing Complete 25mm.....	19
Bearing head for Velding Lift Cyl.....	24
Bearing Head Without Bearing.....	29
Block fitting.....	11
Blower.....	49
Bolt Clutch 2045/60.....	46
Bolt for flange.....	15
Bolt For Lower Joint.....	29
Bolt for Pos. 1+2.....	31
Bolt for Pos. 4.....	37
Bolt Housing 2045/60.....	46
Bolt manifold.....	44
Bracket.....	79
Bracket engine front - side way.....	31
Bracket filter housing.....	43
Bracket for HST.....	31
Bracket for Relay.....	48
Bracket for side way mounting.....	31
Bracket max RPM adjust.....	74
Bracket pressure filter.....	59
Bracket rear.....	21
Brackets battery.....	91
Brackets for rubber mounts Left.....	31
Brackets for rubber mounts Right.....	31
Bracket Steering Cyl.....	19
Brake cable cabin.....	10

Brake cable chassis.....	10
Brake cable Set.....	10
Brake cable Set - brake drums.....	11
Brake Cylinder.....	11
Brake Drum L/R.....	11
Brake fluid reservoir.....	76
Brake hose kit.....	11
Brake pedal complete.....	76
Brake shoes Left.....	11
Brake shoes Right.....	11
Brakket for ST3405.....	18
Break hose Left.....	76
Break hose pressure transmitter.....	76
Break hose Right.....	76
Bulkhead 5/8.....	58
Bushing for Welding.....	29

C

Cabin Filter.....	61
Cabin Locking Bracket 1.....	32
Cabin Locking Bracket 2.....	32
Cable for throttle automatic Trend.....	10
Capacitor.....	59
Cast Tool Set.....	92
Center nut.....	11
Center nut 2045/60+Eco.....	15
Cigar Plug.....	51
Clutch Housing 2045.....	46
Clutch housing 2060.....	46
Clutch "one pice" 2045.....	46
Clutch "one pice" 2060.....	46
Combi instrument.....	50
Connection 1/2" - 16mm.....	22
Connection 3/4" - 1".....	22
Connection 3/4" - 3/4".....	22
Controller complete.....	16, 17
Cover Manoeuvre Console.....	71
Cover Steering Console.....	71
Cover under the roof.....	79
Crossbar horns rear.....	37

D

Directional valve.....	23
Distributing Wiring.....	91
Dobbel Pump Joystick - steering 2045/60.....	20
Door Glass Left Coloured.....	55
Door Glass Right Coloured.....	55
Door Handle.....	52
Door keys.....	52
Draw Bar.....	33
Driving Cable 2045 (Foot throttle).....	10
Dust Cap Black gr.1 FASTER.....	25
Dust Cap Black gr.1 FOSSWINKEL.....	25
Dust Cap Blue gr.1. FASTER.....	25
Dust Cap Blue gr.1 FOSSWINKEL.....	25
Dust Cap red gr.1 FASTER.....	25
Dust Cap red gr.1 FOSSWINKEL.....	25
Dust Cap red gr.2.....	25

E

Emblem Flash Light.....	48
Engine Cover alu top.....	39

Engine Cover front..... 39
 Engine Cover L..... 39
 Engine Cover R..... 39
 Evaporator/Radiator..... 58

F

Fan..... 59
 Fan Contact..... 50
 Fan Push..... 42
 Fan Suction..... 42
 Feed pump..... 16, 17
 Filter Air intake..... 43
 Filter Air intake 2045/2060..... 9
 Filter cabin intake 2045/60..... 9
 Filter Engine oil 2045/60..... 9
 Filter filler cab 2045/60..... 9
 Filter fuel line 2045/60..... 9
 Filter High pressure..... 9
 Filter return flow 2045/60..... 9
 Finger Bolt..... 61
 Fitting adjustable..... 18
 Fitting T - connector..... 76
 Flange 6000 psi Adjustable..... 18
 Flange assy 6000 psi..... 18
 Flange for Motor Front 2045/60..... 15
 Flange for Motor Rear 2045/60..... 15
 Flash arm..... 51
 Flasher relay..... 51
 Flatface gr.1 1/2" Female..... 25
 Flatface gr.1 3/8" Female..... 25
 Flatface gr.2 1/2" Female..... 25
 Flatface gr.2 1/2" Male..... 25
 Flatface gr.2 3/4" Female..... 25
 Flatface gr.2 3/4" Male..... 25
 Flex 7,4mm..... 12
 Flex 13mm..... 12
 Flex 19mm..... 12
 Flex 25mm..... 12
 Flex 28mm..... 12
 Flow control valve..... 23
 Flow control valve is not shown..... 23
 Flow divider valve..... 23
 FNR Switch..... 72
 Front Lift Optimizer..... 27
 Fuel filler cap..... 34
 Fuelfilter bracket..... 34
 Fuel Gauge..... 34
 Fuel pump..... 34
 Fuel Tank 2060/45..... 34
 Fuse box..... 50, 91

G

Gasket for Lift Cyl..... 24
 Gasket manifold..... 44
 Gaskets Steering Cyl..... 19
 Gas lever..... 74
 Gas spring..... 39
 Grille 2045/60..... 41

H

Hand Brake Cable - cabin..... 11
 Handle all engine covers..... 39

Hand Screws..... 39
 Harness Joystick..... 23
 Hatch Hydrostat..... 35
 Hatch Rear Wheel Left..... 35
 Hatch Rear Wheel Right..... 35
 Hazard Contact..... 50
 Headlight Left..... 90
 Headlight Right..... 90
 Head shield..... 44
 Heating valve..... 58
 Heat sensor..... 42
 Hinge for alu top..... 39
 Horn..... 47
 Horn Bracket front..... 37
 Horn Ground Wire..... 47
 Hose capacitor - compressor..... 59
 Hose capacitor - pressure filter..... 59
 Hose compressor - evaporator..... 59
 Hose evaporator - pressure filter..... 59
 Hose intake..... 43
 Hose pipe 1"..... 21
 Hose pipe 3/4"..... 21
 Hyd. Oil Thermostat..... 21
 Hydraulic blok..... 18
 Hydraulic hoses 2045 Trend - 2060 Optimizer..... 95
 Hydraulic pipe Complet..... 18
 Hydrostat 2045..... 16
 Hydrostat 2060..... 17
 HYDSL4010..... 95

I

Inner Bracket Left..... 53
 Inner Bracket Right..... 53
 Inner Door Handle Left..... 52
 Inner Door Handle Right..... 52
 Inner Lower Bracket Left..... 53
 Inner Lower Door Bracket Right..... 53
 Inner Upper Door Bracket Right..... 53
 Intake Grill..... 61
 Isolating A/C Housing..... 68
 Isolating Cabin Rear..... 68
 Isolating coverings Plast Roof..... 66
 Isolating Cover Plate..... 67
 Isolating Floor Mat..... 65
 Isolating for Manoeuvre Box..... 62
 Isolating Maneuver Console..... 68
 Isolating Maneuver Console 2..... 68
 Isolating Rear..... 64
 Isolating Seat Console..... 67
 Isolating Seat Console 2..... 67
 Isolating Seat Console 3..... 67
 Isolating Steering Colum..... 67
 Isolating Steering Console..... 63

J

Joints..... 14
 Joystick Complete..... 72

K

Key Set..... 50
 Key Switch..... 50

L

LED - Control lampe.....	72
Lift cylinder.....	24
Light console L - LED.....	39
Light console R - LED.....	39
Locking Nut.....	19
Locking ring 35mm.....	29
Locking Ring 45 mm.....	29
Locking Ring for Pos 3.....	29
Lock tab front R + L.....	37
Loud Speaker Set.....	48

M

Manchet Lift Cyl.....	24
Manifold exhaust pipe.....	44
Master cylinder.....	76
Medium pressure filter.....	21
Micro relay.....	51
Micro relay starting frame no. 385.....	48
Mirror.....	52
Mirror Arm.....	52
Mode switch.....	72
Mode switch handle.....	72
Motor Funk. Valve.....	23
Mounting Bracket.....	32
Mounting Brackets for joystick block no. 216 - not shown.....	23
Mud Flap.....	36

N

Nippel for A+B port Rear engine.....	15
Nipple for A+B port front engine.....	15
Nipple for drain front engine.....	15
Nipple for drain Rear engine.....	15
Nozzle.....	60

O

Oil level sight glass.....	21
Oil Termostat.....	40
Orbitrol.....	19
O-ring 2060.....	20
O-ring for pos. 1 + 6.....	18
O-ring return filter.....	21
Outer Lower Door Hinge.....	53
Outer Upper Door Hinge.....	53
Outlet exhaust pipe.....	44
Overflow valve.....	23

P

Pakset complete.....	16, 17
Panel Joystick.....	72
Panel - Water adjust.....	72
Pedal.....	76
Pedal 2045/60.....	73
Pedal complete.....	77
Pedal console.....	73
Pedal console with EL9168.....	73
Pedal cover.....	73
Pedal shaft.....	73
Pin Front Lift.....	24

Pin Lift-A-Frame.....	27
Pin Lift-Chassis.....	27
Pin lift Cylinder.....	27
Pin Rear Lift Cyl.....	24
Pin steering Cyl.....	19
Pipe water pump.....	42
Plastic Disc.....	39
Plug + 12V.....	50
Pole shoe -.....	91
Pole shoe +.....	91
Pollen Filter.....	61
Pom Fazet Washer.....	53
Pom Flat Washer.....	53
Potentiometer.....	77
Potentometer.....	72
Potentometer handle.....	72
Potentometer - small PTO.....	72
Preheater relay.....	51
Press contact.....	59
Pressure filter.....	59
Pressure relief valve buster pressure.....	16, 17
Pressure relief valve forward.....	16
Pressure relief valve forward / reverse adjustable.....	17
Pressure relief valve reverse.....	16
Pressure sensor.....	59
Pressure transducer.....	77
PTO contact.....	50
PTO contact Holding.....	50
PTO Pump 2045.....	20
PTO Pump 2060.....	20

R

Radiator.....	58
Radiator 2045/60.....	40
Radiator cap.....	40
Radiator Hose.....	42
Radiator Hose top.....	42
Radiator Hose water pump.....	42
Radio and CD Player.....	48
Rear Window Coloured.....	56
Regulator arm.....	74
Relay immobilizer.....	51
Relay main flow.....	51
Rep kit master cylinders.....	76
Return Block 3/4 - 1/2.....	21
Return Block 3/4 - 1/4.....	21
Return filter complete.....	21
Rivets.....	69
Rocker switch - float - On/Off.....	72
Rocker switch - Small PTO.....	72
Roof.....	79
Rubber grommet.....	14
Rubber Mount.....	14
Rubber mounting - Cabin front.....	78
Rubber mounting - Cabin rear.....	78
Rubber mounting - side way.....	31
Rubber Washer.....	40

S

Seat Air Suspended.....	75
Shelf with plastic roof.....	48
Shock valve forward / reverse nonadjustable.....	17

Shut-off valve.....	23
Shut-off Valve Lift.....	23
shutoff valve lift.....	23
Side Cover L.....	51
Side Cover R.....	51
Side Window Coloured.....	56
Silencer 2045/60.....	44
Sims 22x1 mm.....	27
Socket for Beacon flasher.....	90
Socket rocker switch.....	72
Steering column.....	47
Steering Cyl.....	19
Steering Wheel.....	47
Steering wheel center.....	47
Step Left.....	28
Step Right.....	28
Sticker "2045 Trend".....	80
Sticker "2060 Optimizer".....	80
Sticker "Engine Cover L".....	80
Sticker engine cover L.....	39
Sticker "Engine Cover R".....	80
Sticker engine cover R.....	39
Sticker - Triangle.....	80
Sticker "Vitra".....	80
Sticker Vitra.....	39
Suction Hose 1".....	22
Suction Hose 3/4".....	22
Suction Hose 16mm.....	22
Suction Hose Clamp 1".....	22
Suction Hose Clamp 1/2".....	22
Support Bracket cowling L.....	37
Support Bracket cowling R.....	37
Support bracket L.....	39
Support bracket R.....	39
Swing Bracket front.....	34
Swing lock R + L.....	37
Switches.....	48
Switching magnet.....	14

T

Taillight Left.....	90
Taillight Right.....	90
Tank 2045/60.....	21
Tape to pedal.....	73
Thermostat.....	42
Test adapter.....	16
Threaded rod.....	91
Throttle cable 2045/60.....	74
Throttle cable 2060/45 (Handthrottle).....	10
Throttle cable 2060 (Foot throttle).....	10
Top Link.....	27
Trailer socket.....	90
Tredo 1/4.....	15
Tredo 3/4.....	15
Tredo sealing.....	18

U

Unbraco Bolt Mud Flap.....	36
Upper Bearing Pin.....	29
Upper Connection.....	29


V

Valve connector - loose.....	23
Valve - Water adjust.....	72
V-Belt 2045/60.....	9
V-Belt A/C 2045/60.....	9

W

Wheel Bolt.....	13
Wheel complete 2045.....	13
Wheel complete 2060.....	13
Wheel hub behind.....	11
Wheel Motor Front 2045 TMK 250.....	15
Wheel Motor Front 2060 TMK 315.....	15
Wheel Motor Rear 2045 TMK 250.....	15
Wheel Motor Rear 2060 TMK 315.....	15
Wheel Nut.....	11
Wind Screen Buttom Coloured.....	54
Wind Screen Top Coloured.....	54
Wiper arm.....	57
Wiper blade.....	57
Wiper Complete set.....	57
Wiper Contact.....	50
Wiper Motor.....	57
Wiring Cabin.....	84
Wiring chassis.....	89
Wiring Chassis to Roof.....	85
Wiring Engine.....	87
Wiring Headlight roof back.....	83
Wiring Headlight roof front.....	83
Wiring headlights.....	88
Wiring PTO-valve.....	86
Wiring Radio Panel.....	82
Wiring Seat.....	81
Wiring Taillight.....	89
Working light Front.....	90
Working light Front double.....	90
Working light Rear.....	90

FIG. 1 SERVICE PARTS




KEY	PART CODE	DESCRIPTION	DIV
1	MOT2082	Filter Air intake 2045/2060	
2	HYD1927	Filter return flow 2045/60	
3	HYD1912	Filter filler cab 2045/60	
4	MOTC1520	Filter Engine oil 2045/60	
5	MOTC1530	Filter fuel line 2045/60	
6	DIV2070	Filter cabin intake 2045/60	
7	KØ5070	V-Belt 2045/60	
8	KØ5010	V-Belt A/C 2045/60	
9	HYD1922	Filter High pressure	

FIG. 2 CABLES



KEY	PART CODE	DESCRIPTION	DIV
1a	DIV4147	Brake cable chassis	
1	DIV4128	Brake cable cabin	
2	DIV4117A	Throttle cable 2060 (Foot throttle)	
3	DIV41	Throttle cable 2060/45 (Handthrottle)	
4	DIV4117	Driving Cable 2045 (Foot throttle)	
5	DIV4140	Brake cable Set	
6	DIV41	Cable for throttle automatic Trend	

FIG. 3 BRAKES 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1L	BR1321	Brake shoes Left	
1R	BR1320	Brake shoes Right	
2	BR1310	Brake Cylinder	
3	BR1025	Brake Drum L/R	
4	HJ5150	Wheel Nut	
5	BM5207	Anchor Plate bolt	
6	HYD4802	Block fitting	
7	HYD1730	Center nut	
8	BR2020	Brake hose kit	
9	DIV4128	Hand Brake Cable - cabin	
9a	DIV4147	Brake cable Set - brake drums	
10	ST1070	Wheel hub behind	

BR2020 Includes


Right side	BR2012
Left side	BR2010
Center	BR2014

FIG. 4 PROTECTIVE FLEX




KEY	PART CODE	DESCRIPTION	DIV
1	DIV6030	Flex 28mm	1 Meter
2	DIV6020	Flex 25mm	1 Meter
3	DIV6018	Flex 19mm	1 Meter
4	DIV6014	Flex 13mm	1 Meter
5	DIV6010	Flex 7,4mm	1 Meter

FIG. 5 WHEEL




KEY	PART CODE	DESCRIPTION	DIV
1	HJ1033	Wheel complete 2045	
2	HJ1037	Wheel complete 2060	
3	HJ5150	Wheel Bolt	

FIG. 6 DIRECTION SELECTOR 2045




KEY	PART CODE	DESCRIPTION	DIV
1	EL1312	Switching magnet	
2	GU5025	Rubber Mount	
3	ST9022	Bearing	
4	GU1105	Rubber grommet	
5	ST9020	Bearing	
6	ST3379	Bushing	
7	BM9010	Joints	

FIG. 7 WHEEL MOTORS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	ST9435	Flange for Motor Front 2045/60	
2	ST9430	Flange for Motor Rear 2045/60	
3	HYD1740	Wheel Motor Front 2045 TMK 250	
4	HYD1744	Wheel Motor Front 2060 TMK 315	
5	HYD1748	Wheel Motor Rear 2045 TMK 250	
6	HYD1752	Wheel Motor Rear 2060 TMK 315	
7	HYD1730	Center nut 2045/60+Eco	
8	HYD4746	Nipple for drain front engine	
9	HYD4745	Nipple for A+B port front engine	
10	BM5255	Bolt for flange	
11	BM5255	Bolt for flange	
12	HYD4710	Nipple for drain Rear engine	
13	HYD4723	Nippel for A+B port Rear engine	
14	HYD5310	Tredo 1/4	
15	HYD5322	Tredo 3/4	

FIG. 8 HYDROSTAT 2045




KEY	PART CODE	DESCRIPTION	DIV
1	HYD1150	Hydrostat 2045	
2	HYD1160	Controller complete	
3	HYD1163	Pakset complete	
4	HYD1166	Feed pump	
5	HYD1169	Pressure relief valve reverse	
6	HYD1172	Pressure relief valve forward	
7	HYD1175	Pressure relief valve buster pressure	
8	HYD9153	Test adapter	

FIG. 9 HYDROSTAT 2060




KEY	PART CODE	DESCRIPTION	DIV
1	HYD1360	Hydrostat 2060	
2	HYD1365	Controller complete	
3	HYD1368	Pakset complete	
4	HYD1371	Feed pump	
5	HYD1374	Pressure relief valve forward / reverse adjustable	
6	HYD1377	Shock valve forward / reverse nonadjustable	
7	HYD1380	Pressure relief valve buster pressure	
8	HYD9153	Test adapter	

FIG. 8 HYDROSTAT 2060




KEY	PART CODE	DESCRIPTION	DIV
1	HYD5513	Flange 6000 psi Adjustable	
2	HYDR2018	Hydraulic pipe Complet	
3	HYD4827	Fitting adjustable	
4	HYD5520	O-ring for pos. 1 + 6	
5	HYD5517	Flange assy 6000 psi	
6	HYD5514	Flange assy 6000 psi	
7	HYD5044	Nippel	
8	HYD5340	Tredo sealing	
9	HYD5044	Nippel	
10	ST3405	Hydraulic blok	
11	ST2574	Brakket for ST3405	

FIG. 10 STEERING COMPONENTS




KEY	PART CODE	DESCRIPTION	DIV
1	HYD2316	Steering Cyl.	
1A	HYD2325	Gaskets Steering Cyl.	
2	HYD2317	Bearing Complete 25mm	
3	HYD2317B	Bearing 25mm	
4	HYD1552	Orbitrol	
5	ST3044A	Bracket Steering Cyl.	
6	ST3322	Pin steering Cyl.	
7	ST3312	20mm pin	
8	ST1079	Locking Nut	

FIG. 11 PUMPS




KEY	PART CODE	DESCRIPTION	DIV
1	HYD1565	PTO Pump 2060	
2	HYD1660	O-ring 2060	
3	HYD1560	PTO Pump 2045	
4	HYP2020	O-ring	
5	HYP1090	Dobbel Pump Joystick - steering 2045/60	
6	HYP2040	O-ring	
7		Ask	
8		Ask	
9			
10			
11			
12			
13			
14			

FIG. 12 HYDRAULIC TANK 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	ST7011	Tank 2045/60	
2	HYD1910	Filling	
3	HYD1925	Return filter complete	
4	ST3126	Bracket rear	
5	ST3413	Return Block 3/4 - 1/2	
6	ST3414	Return Block 3/4 - 1/4	
7	KØ9010	Hyd. Oil Thermostat	
8	HYD1950	Oil level sight glass	
9	ST3127	Bracket front	
10	FI1420	Hose pipe 3/4	
11	FI1410	Hose pipe 1"	
12	HYD4960	Adaptor	
13	HYD5410	Unbraco plug	
14	HYD1920	Medium pressure filter	
15	GU4624	O-ring return filter	

FIG. 13 SUCTION HOSE 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	HYD7069	Suction Hose 16mm	1 Meter
2	HYD7070	Suction Hose 3/4"	1 Meter
3	HYD7120	Suction Hose 1"	1 Meter
4	FI1350	Connection 1/2" - 16mm	
5	FI1420	Connection 3/4" - 3/4"	
6	FI1410	Connection 3/4" - 1"	
7	BM9215	Suction Hose Clamp 1/2"	
8	BM9220	Suction Hose Clamp 1"	

FIG. 14 JOYSTICK SYSTEM 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	HYD2220	Directional valve No. 216 -	
2	HYD2222	Shut-off valve No. 216 (+ shutoff valve lift No. 216-290)	
3	HYD2224	Motor Funk. Valve No. 216 (+ Flow divider valve No. 216-290)	
4	HYD2227	Overflow valve No. 216-290	
5	HYD2226	Overflow valve No. 291 -	
6	HYD2228	Flow control valve No. 216 -	
7	HYD2230	Shut-off Valve Lift No. 291 -	
8	HYD2232	Flow divider valve Nr. 291 -	
9	HYD1987	Flow control valve is not shown	
10	ST3045	Mounting Brackets for joystick block no. 216 - not shown	
11	HYD1855	Valve connector - loose	
12	EL9018	Harness Joystick	

FIG. 15 FRONT LIFT 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	HYD2322	Lift cylinder	
2	HYD2317A	Bearing head for Velding Lift Cyl.	
3	HYD2317B	Bearing 25mm Lift Cyl.	
3a	HYD2317	Bearing head for Velding Lift Cyl.	
4	ST4210	Pin Front Lift.	
5	GU5110	Manchet Lift Cyl.	
6	ST4265	Pin Rear Lift Cyl.	
7	HYD2325	Gasket for Lift Cyl.	


FIG. 16 QUICK COUPLERS 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	HYD4001	Flatface gr.2 3/4" Female	
2	HYD4010	Flatface gr.2 1/2" Female	
3	HYD5060	3/4" Bulk	
4	HYD5322	3/4" Tredo Ring	
5	HYD4019	Flatface gr.1 1/2" Female	
6	HYD4018	Flatface gr.1 3/8" Female	
7	HYD5058	1/2" Bulk	
8	HYD5318	1/2" Tredo Ring	
9	HYD4004	Flatface gr.2 3/4" Male	
10	HYD4014	Flatface gr.2 1/2" Male	
11	HYD5054	3/8" Bulk	
12	HYD5314	3/8" Tredo Ring	
13	GU4570	Dust Cap red gr.2	
14	GU4564	Dust Cap red gr.1 FOSSWINKEL	++
15	GU4560	Dust Cap Black gr.1 FOSSWINKEL	++
16	GU4562	Dust Cap Blue gr.1 FOSSWINKEL	++
14A	GU4559	Dust Cap red gr.1 FASTER	--
15A	GU4560	Dust Cap Black gr.1 FASTER	--
16A	GU4557	Dust Cap Blue gr1. FASTER	--


++ Use up to chassis number 384
 -- Use from chassis number 385

FIG. 17 QUICK COUPLERS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	HYD4007	3/4" Flatface Female	
1A	HYD4004	3/4" Flatface Male	
1B	HYD5060	3/4" Skot	
1C	HYD5322	3/4" Tredo Ring	
2	HYD4050	Flatface 1/2" Female	
2A	HYD4054	Flatface 1/2" Male	
2B	HYD5058	1/2" Bulk	
2C	HYD5318	1/2" Tredo Ring	
3	HYD4046	Flatface 3/8" Female	
3A	HYD4048	Flatface 3/8" Male	
3B	HYD5054	3/8" Bulk	
3C	HYD5314	3/8" Tredo Ring	
	GU4510	Dust Cap 3/8 Female	
	GU3525	Dust Cap 3/8 Male	
	GU3510	Dust Cap 1/2 Female	
	GU3515	Dust Cap 1/2 Male	
	GU4530	Dust Cap til flatface 3/4 han	
	GU4532	Dust Cap til flatface 3/4 hun	

FIG. 18 A-FRAME 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	ST4010	A-Frame Cat 1.	
2	ST9115	Pin Lift-A-Frame	
3	ST3810	Top Link	
4	BM8010	Bolt	
5	BM1870	Bolt	
6	ST9117	Pin	
7	BM8090	Nut	
8	BM2670	Washer	
9	STL1057	Front Lift Optimizer	
10	ST4100	Pin Lift-Chassis	
11	ST1510	Bearing complete	
12	BM2950	Sims 22x1 mm	
13	ST4210	Pin lift Cylinder	

FIG. 19 STEPS 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	ST3059	Step Left	
2	ST3060	Step Right	

FIG. 20 CENTRE LINKAGE 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	ST3027B	Upper Connection	
2	ST1135	Locking ring 35mm	
3	ST3349	Upper Bearing Pin	
4	ST1127	Locking Ring for Pos 3	
5	BM6032	Bolt For Lower Joint	
6	ST1119	Bearing Head Without Bearing	
7	ST1117B	Bearing 45mm	
8	ST3336	Bushing for Welding	
9	ST1115	Bearing 35mm	
10	ST1140	Locking Ring 45 mm for pos. 6	
11	BM6040	Locking Bolt For Pos. 5	
12	BM2547	Washer For Pos. 5	

FIG. 21 ENGINE MOUNTINGS 2045

In development


KEY	PART CODE	DESCRIPTION	DIV
1			
2			
3			
4			
5			
6			
7			
8			

FIG. 21 ENGINE MOUNTINGS 2060



KEY	PART CODE	DESCRIPTION	DIV
1	ST3058	Brackets for rubber mounts Right	
2	ST3056	Brackets for rubber mounts Left	
3	BM1960	Bolt for Pos. 1+2	
4	GU5023	Rubber mounting for Pos. 1+2+8	
5	ST3143	Bracket engine front - side way	
6	GU3013	Rubber mounting - side way	
7	ST3551	Bracket for side way mounting	
8	ST3047B	Bracket for HST	

FIG. 23 CHASSIS PARTS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	ST3034	Cabin Locking Bracket 1	
2	ST3036	Cabin Locking Bracket 2	
3	ST3037	Mounting Bracket	

FIG. 24 TRAILER HITCH




KEY	PART CODE	DESCRIPTION	DIV
1	ST3070	Draw Bar	
2	ST9140	Ball Bar	

FIG. 25 FUEL TANK 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	ST7021B	Fuel Tank 2060/45	
2	EL2519A	Fuel Gauge	
3	ST7028	Fuel filler cap	
4	ST3032B	Swing Bracket front	
5	ST3101	Support Bracket	
6	ST3031A	Stop Bracket	
7	ST7018	Lock	
8	GU5021	Rubber	
9	FI1530	Nipple	
10	FI1525	Nipple	
11	MOTC1552	Fuel pump	
12	ST2533	Fuelfilter bracket	

FIG. 26 HATCHES 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	ST3023	Hatch Rear Wheel Right	
2	BM1110	Bolt	
3	ST3018	Hatch Hydrostat	
4	BM1118	Bolt	
5	BM2020	Nut	
6	ST3018	Hatch Hydrostat	
7	ST3022	Hatch Rear Wheel Left	

FIG. 27 MUD FLAPS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	GU4010	Mud Flap	
2	BM5420	Unbraco Bolt Mud Flap	
3	BM2805	Washer	

FIG. 28 REAR ATTACHMENT POINTS 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	ST3550	Horn Bracket front	
2	ST3555	Support Bracket cowling L	
3	ST3560	Support Bracket cowling R	
4	FS6718	Lock tab front R + L	
5	BM5255	Bolt for Pos. 4	
6	FSB415	Swing lock R + L	
7	ST3115	Crossbar horns rear	

FIG. 29 ENGINE COVERS 2045/60




See next page

FIG. 29 ENGINE COVERS 2045/60


KEY	PART CODE	DESCRIPTION	DIV
1	GF2060	Engine Cover L	
2	GF2065	Engine Cover R	
3	GF2072	Engine Cover front	
4	ST3570	Engine Cover alu top	
5	GF2074	Light console L - LED	
6	GF2076	Light console R - LED	
7	DIV5120	Sticker engine cover L	
8	DIV5125	Sticker engine cover R	
9	DIV2050	Sticker Vitra	
10	FS6500	Rubber Lock	
11	DIV2132	Hand Screws	
12	DIV8025	Handle all engine covers	
13	DIV4310	Gas spring	
14	FS4210	Adjust screw	
15	ST3565	Support bracket L	
16	ST3565	Support bracket R	
17	DIV2230	Hinge for alu top	
18	GU6650	Plastic Disc	

FIG. 31 COOLING SYSTEM 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	KØ1075	Radiator 2045/60	
2	GU1040	Rubber Washer	
3	KØ2020	Radiator cap	
4	KØ9010	Oil Termostat	

FIG. 32 COOLING SYSTEM 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	ST3065B	Grille 2045/60	
2	GU6022	Rubber Edge	1 m
3	ST2555	Grille Lock	
4	DIV2240	Hinge for grill	

FIG. 33 COOLING SYSTEM 2045/2060




KEY	PART CODE	DESCRIPTION	DIV
1	MOTC6100	Fan Suction	
2	MOTC6110	Fan Push	
3	MOTC6009	Spacer	
4	GU2132	Radiator Hose top	
5	MOTC6050	Thermostat	
6	EL2525	Heat sensor	
7	MOTC6540	Pipe water pump	
8	MOT1065	Radiator Hose	
9	GU2118	Radiator Hose water pump	

FIG. 36 AIR FILTER 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	MOT2080	2060 Filter complete	
2	MOT2085	Bracket filter housing	
3	MOT2082	Filter Air intake	
4	MOT2047	Hose intake	1 m
5	BM6265	Clamp	

FIG. 37 EXHAUST PARTS 2045




KEY	PART CODE	DESCRIPTION	DIV
1	ST3072G	Head shield	
2	MOTC5035	Manifold exhaust pipe	
3	MOTC5018	Gasket manifold	
4	BM5655	Bolt manifold	
5	ST9033	Spring	
6	MOTC5038	Silencer 2045/60	
7	ST3072H	Heat shield	
8	BM9262	Clamps	
9	GU3020	Rubber mount	
10	MOTC5025	Outlet exhaust pipe	

FIG. 38 EXHAUST PARTS 2060




KEY	PART CODE	DESCRIPTION	DIV
1	ST3072G	Heat shield	
2	MOTC5036	Manifold Exhaust pipe	
3	MOTC5018	Gasket manifold	
4	BM5655	Bolt manifold	
5	ST9033	Spring	
6	MOTC5038	Silencer 2045/60	
7	ST3072H	Heat shield	
8	BM9262	Clamp	
9	ST3020	Rubber mount	
10	MOTC5025	Outlet exhaust pipe	

FIG. 39 CLUTCH 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	MOT9045	Clutch housing 2060	
2	MOT9007	Clutch "one pice" 2060	
3	BM2345	Bolt Clutch 2045/60	5/16x3/4
4	BM2347	Bolt Housing 2045/60	3/8x1 1/4
5	MOT9040	Clutch Housing 2045	
6	MOT9003	Clutch "one pice" 2045	

FIG. 42 STEERING COLUMN / HORN 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	RAT1020	Steering column	
2	RAT3005	Steering Wheel	
3	RAT3006	Steering wheel center	
4	EL2520	Horn	
5	EL9152	Horn Ground Wire	

FIG. 43 RADIO SHELF 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	ST3245	Shelf with plastic roof	
2	EL1010	Loud Speaker Set	
3	EL1115	Switches	
4	EL1157	Emblem Flash Light	
5	EL1170	Frame	
6	EL4010	Relay	
6a	EL4020	Micro relay starting frame no. 385	
7	DIV3070	Bracket for Relay	
8	DIV3058	Strips	
9	EL8510	Fuse	
10	EL1031	Fuse Box	
11	BM3002	Screw	
12	BM2515	Washer	
13	BM2001	Nut	
14	EL1185	Cover	
15	EL1018	Radio and CD Player	
16	EL1010	Loud Speaker Set	
17	EL9200	Wiring	

FIG. 44 BLOWER 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV1525	Blower	
2	BM3015	Bolt 5X16 mm	
3	DIV6014	Flex 90 cm	
4	EL9125	Wiring	

FIG. 45 DASH BOARD 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	RAT3001	Top cover	
2	RAT3030	Combi instrument	
3	RAT	PTO contact Holding	
4	RAT3050	PTO contact (Symbol RAT3064)	
4a	RAT	PTO contact impuls	
5	RAT3054	Hazard Contact (Symbol RAT3065)	
6	RAT3070	Blanking cover	
7	RAT3056	Fan Contact (Symbol RAT3066)	
8	RAT3058	Wiper Contact (Symbol RAT3067)	
9	RAT3021	Key Set	
10	RAT3020	Key Switch	
11	RAT3075	Fuse box	
12	EL2540	Plug + 12V	

FIG. 46 DASH BOARD ELECTRONIC PARTS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	RAT3004	Side Cover L	
2	RAT3003	Side Cover R	
3	RAT3003	Diode	
4	RAT3046	Flasher relay	
5	RAT3040	Relay immobilizer	
6	EL4020	Micro relay (High / low light and a / c)	
7	EL4014	Relay main flow	
8	RAT3010	Flash arm	
9	RAT3044	Preheater relay	
10	EL2540	Cigar Plug	

FIG. 47 DOOR PARTS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV2312	Inner Door Handle Right	
1A	DIV2310	Inner Door Handle Left	
2	DIV2332	Cover Right	
2A	DIV2330	Cover Left	
3	DIV2342	Small Cover Right	
3A	DIV2340	Small Cover Left	
4	DIV2345	Bent Cover	
5	GL2025	Washer	
6A	DIV2370	Door keys	
6	DIV2320	Door Handle	
7	DIV2350	Rubber Washer 1	
8	DIV2360	Rubber Washer 2	
9	DIV2380	Trolling	
10	DIV8010	Mirror Arm	
11	ST3098	Bracket	
12	DIV8021	Mirror	
9A	DIV2390	Coverage For Trolling	
9B	DIV2385	Threaded Bracket	
9C	DIV2385	Washer	

FIG. 48 DOOR PARTS 2045/60





KEY	PART CODE	DESCRIPTION	DIV
1	ST3211	Inner Bracket Left	
1A	ST3215	Inner Bracket Right	
2	DIV2335	Angle Mounting	
3	ST3222	Inner Upper Door Bracket Right	
4	ST3227	Inner Lower Door Bracket Right	
5	ST3238	Outer Upper Door Hinge	
6	GL2010	Pom Flat Washer	
7	GL2020	Pom Fazet Washer	
8	ST3230	Outer Lower Door Hinge	
9	ST3219	Inner Lower Bracket Left	
10	GU6012	Rubber Strip	

FIG. 49 WIND SCREEN 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	GL1510	Wind Screen Top Coloured	
2	GL1514	Wind Screen Buttom Coloured	

FIG. 50 DOOR GLAS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	GL1524	Door Glass Right Coloured	
2	GL1518	Door Glass Left Coloured	

FIG. 51 / WINDOWS REAR 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	GL1535	Rear Window Coloured	
2	GL1528	Side Window Coloured	

FIG. 52 WIPER 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	VI4013	Wiper Motor	
2	VI2030	Roset	
3	VI2097	Rubber	
4	VI4011	Wiper arm	
5	VI4012	Wiper blade	
6	DIV8021	Mirror	
7	VI4010	Wiper Complete set	

FIG. 53 CABIN HEATING/A/C PARTS 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	DIV2009	Radiator	
2	AC2526	Evaporator/Radiator	
3	GU2110	Radiator Hose	1 Meter
4	BM9210	Hose clamp	
5	DIV2036	Handle	
6	DIV2035	Heating valve	
7	HYD5102	Taper	
8	AC8040	A/C Hose thin evaporator	
9	AC8041	A/C Hose thick evaporator	
10	AC5022	Bulkhead 5/8	
11	AC5020	Bulkhead 7/8	


FIG. 54 CABIN HEATING/A/C PARTS



KEY	PART CODE	DESCRIPTION	DIV
1	AC3020	Fan	
2	AC2545	A/C House vers.2	
3	GU6070	Rubber seal	
4	GU5020	Vibration damper	
5	GU6027	Rubber seal	
6	AC2541	Capacitor	


KEY	PART CODE	DESCRIPTION	DIV
1	AC8042	Hose capacitor - pressure filter	
2	AC8043	Hose evaporator - pressure filter	
3	AC8044	Hose capacitor - compressor	
4	AC8045	Hose compressor - evaporator	
5	AC2531	Press contact	
6	AC2538	Pressure sensor	
7	AC2530	Pressure filter	
8	AC2532	Bracket pressure filter	

FIG. 55 CABIN VENTILATION PARTS 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	DIV2040	Nozzle	
2	BM3530	Screw	
3	DIV1550	Nozzle	

FIG. 56 CABIN VENTILATION PARTS 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	DIV2050	Intake Grill	
2	DIV2072	Cabin Filter	
3	DIV2130	Finger Bolt	
4	DIV2070	Pollen Filter (No Picture)	Option

FIG. 57 CABIN ISOLATING 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	DIV10504	Isolating for Manoeuvre Box	

FIG. 58 CABIN ISOLATING 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV10502	Isolating Steering Console	

FIG. 59 CABIN ISOLATING 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV10503	Isolating Rear	

FIG. 60 CABIN ISOLATING 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV1052B	Isolating Floor Mat	

FIG. 61 CABIN ISOLATING 2045/60




KEY	PART CODE	DESCRIPTION	DIV
2	DIV1051A	Isolating coverings Plast Roof	

FIG. 62 CABIN ISOLATING 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV1025	Isolating Steering Colum	
2	DIV1027	Isolating Seat Console	
3	LS9813	Isolating Cover Plate	
4	BM2020	Nut	
5	ST3510	Bolt	
6	BM2620	Washer	
7	BM2531	Washer Large	
8	DIV1042	Isolating Seat Console 2	
9	DIV1030	Isolating Seat Console 3	

FIG. 63 CABIN ISOLATING 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV1036	Isolating Maneuver Console	
2	DIV1034	Isolating Maneuver Console 2	
3	DIV1040	Isolating Cabin Rear	
4	DIV1044	Isolating A/C Housing	
5	DIV1038	Isolating Maneuver Console	

FIG. 64 CABIN PARTS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV1054	Alu Rail Left Door	
2	DIV1055	Alu Rail Right Door	
3	ST9135	Rivets	

FIG. 65 CABIN PARTS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	ST3095A	Bottom plate	
2	ST30914	Flange for Manchet	
3	GU5150	Manchet for cable	
4	GU1116	Clamp	
5	GU1012	Rubber bush	
6	GU1026	Rubber bush	
7	GU6072	Rubber strip 4x10	
8	GU6070	Rubber strip 5x14	
9	BM1118	Bolt	
10	BM2795	Washer	
11	BM3505	Screw	

FIG. 66 CABIN COVERS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	BM3110	Bolt	
2	BM3015	Bolt	
3	BM8210	Threaded Rod	
4	BM2020	Nut	
5	LS9804	Cover Manoeuvre Console	
6	LS9808	Cover Steering Console	

FIG. 67 MANEUVER PANEL 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	STL2204	Joystick Complete	
2	EL2215	FNR Switch	
3	LS9508	Panel Joystick	
4	EL1170	Socket rocker switch	
5	EL1115	Rocker switch - float - On/Off	
6	EL1105	Rocker switch - Small PTO	
7	EL1120	Socket FNR Symbols	
8	EL1185	Socket Cap	
9	EL1167	Symbol - Float funktion	
10	EL1130	Symbol - Small PTO	
11	EL1168	Symbol - On/Off	
12	EL1149	Symbol - Forward	
13	EL1148	Symbol - Backward	
14	LS9510	Panel - Water adjust	
15	FS4049	Valve - Water adjust	
16	EL2089	Potentometer - small PTO	
17	EL2167	Mode switch handle	
18	EL2166	Mode switch	
19	EL2076	LED - Control lampe	
20	EL2093	Potentometer handle	
21	EL2092	Potentometer	

FIG. 68 PEDAL 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	ST3585	Pedal 2045/60	
2	DIV1059	Tape to pedal	1 M
3	ST3590	Pedal console	
3a	ST	Pedal console with EL9168	
4	ST3595	Pedal cover	
5	ST1120	Circlip	
6	ST1188	Pedal shaft	
7	DIV4154	Lock	
8	BM1250	Bolt	
9	FS6415	Bushing	
10	ST3053	Cable Support	
11	LS12113	Brackets	
12	BM9010	Angled ball	1 Stk
13	ST9016	Spring	

FIG. 71 THROTTLE PARTS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV4115	Throttle cable 2045/60	
2	ST3271	Support bracket for pos. 6	
3	DIV4109	Gas lever 2045/60	
4	GL2010	Washer plast	
5	ST3273	Bracket for cabel	
6	ST3274	Regulator arm	
7	ST3272	Bracket max RPM adjust	
8	ST9133	Lock	
9	ST9134	Pin	

FIG. 72 SEAT 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV1085	Seat Air Suspended	

FIG. 69 BRAKE PEDAL 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	BR1510	Brake pedal complete.	
2	BR1508	Rep kit master cylinders.	
3	BR1511	Master cylinder	
4	BR1509	Pedal	
5	BR2010	Break hose Left	
6	BR2012	Break hose Right	
7	BR2014	Break hose pressure transmitter	
8	HYD4847	Fitting T - connector	
9	HYD4705	Fitting nippel	
10	HYD5415	Closing plug	
11	BR1514	Brake fluid reservoir	
12	BR1512	Lock clips for pos.11	

FIG. 68 PEDAL 2060




KEY	PART CODE	DESCRIPTION	DIV
1	EL9168	Pedal complete	
2	GU4004	Rubber	
3	EL9169	Potentiometer	
4	BR1525	Pressure transducer	
5	HYD4948	Fitting for pos. 4	
6	EL9037	Wiring	

FIG. 73 CABIN SUSPENSIONS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	GU3016	Rubber mounting - Cabin front	
2	BM1838	Bolt	
3	BM2635	Washer	
4	BM2051	Locking not	
5	GU3008	Rubber mounting - Cabin rear	

FIG. 74 ROOF 2045/60




KEY	PART CODE	DESCRIPTION	DIV
2	GF2025	Roof	




KEY	PART CODE	DESCRIPTION	DIV
1	ST3580	Cover under the roof	
2	ST3582	Bracket	
3	GU6069	Rubber	
4	GU1045	Rubber Washer	
5	BM5410	Bolt	

FIG. 75 STICKERS 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	DIV5010	Sticker - Triangle	
2	DIV5050	Sticker "Vitra"	
3	DIV5049	Sticker "2060 Optimizer"	
4	DIV5046	Sticker "2045 Trend"	
5	DIV5120	Sticker "Engine Cover L"	
6	DIV5125	Sticker "Engine Cover R"	

FIG. 76 WIRING SEAT 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	EL9007	Wiring Seat	

FIG. 77 WIRING RADIO PANEL 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	EL9108	Wiring Radio Panel	

FIG. 78 WIRING ROOF 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	EL9113	Wiring Headlight roof front	
2	EL9114	Wiring Headlight roof back	
3	HYD4780	Clamp	

FIG. 79 WIRING CABIN 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	EL9020	Wiring Cabin	

FIG. 80 WIRING DOOR FRAME RIGHT TO ROOF 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	EL9122	Wiring Chassis to Roof	

FIG. 81 WIRING PTO VALVE 2045/60




KEY	PART CODE	DESCRIPTION	DIV
1	EL9065	Wiring PTO-valve	

FIG. 82 WIRING ENGINE 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	EL9036	Wiring Engine	

FIG. 81 WIRING HEADLIGHTS 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	EL9109	Wiring headlights	
2	EL8137	Multi connector	
3	EL9223	Rubber seal for pos. 2	Not illu.

FIG. 83 WIRING CHASSIS 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	EL9015A	Wiring chassis	
2	EL9048	Wiring Taillight	Not illu.

FIG. 84 LIGHTING 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	EL9222	Headlight Right	
2	EL9220	Headlight Left	
3	EL2000	Working light Front	
3a	EL2002	Working light Front double	
4	EL2005	Working light Rear	
5	EL2007	Taillight Left	
5a	EL2008	Taillight Right	
6	EL2021	Socket for Beacon flasher	
7	EL2020	Beacon flasher	
8	EL2544	Trailer socket	


FIG. 85 BATTERY 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	EL1057	Battery	
2	EL8546	Fuse box	
2a	EL8550	40A Fuse	Not illu.
4	EL3310	Pole shoe +	
5	EL3312	Pole shoe -	
6	EL9215	Distributing Wiring	**
7	ST3075	Brackets battery	
8	BM8212	Threaded rod	


**** UP UNTIL....frame number. 384 ****

FIG. 87 CONNECTORS AND TOOLS




KEY	PART CODE	DESCRIPTION	DIV
1	VÆ7010	Cast Tool Set for pos. (16-17-22-23)	
2	VÆ7012	Cast Tool for Pos. (28-29)	
2A	VÆ7015	Cast tool for pos. 4	
3	EL4010	Relay Standard	
4	EL4020	Micro-Relay	
5	EL4022	Socket for Micro-relay	
6	EL8110	Socket for relay Standard	
7	EL1119	Connector for SWF Switches	
8	EL8190	Connector Generator	
9	EL8165	6 Pin Super seal Male	
9A	EL8167	6 Pin Super seal Female	
10	EL8160	3 Pin Super seal Male	
10A	EL8161	3 Pin Super seal Female	
11	EL8158	2 Pin Super seal Male	
11A	EL8159	2 Pin Super seal Female	
12	EL8182	Pins super seal Female	
13	EL8180	Pins super seal Male	
14	EL3514	Multi Connector Female 19 + 20 Pin ITT-Canon	

FIG. 88 CONNECTORS AND TOOLS



KEY	PART CODE	DESCRIPTION	DIV
14A	EL3512	Multi Connector Male 19+20Pin ITT-Canon	
15	EL3514	Multi Connector Female 19 Pin ITT-Canon	
15A	EL3505	Multi Connector Male 19 Pin ITT-Canon	
16	EL3525	Pin Signal for ITT-Canon Male Connector	
16A	EL3527	Pin Signal for ITT-Canon Female Connector	
17	EL3530	Pin Power for ITT-Canon Male Connector	
17A	EL3532	Pin Power for ITT-Canon Female Connector	
18	EL3555	UMNL Connector 12 Pin Male	
18A	EL3550	Multi UMNL Connector 12 Pin female	
19	EL3547	Multi UMNL Connector 6 Pin Male	
19A	EL3541	Multi UMNL Connector 6 Pin Female	
20	EL3540	Multi UMNL Connector 9 Pin Male	
20A	EL3542	Multi UMNL Connector 9 Pin Female	
21	EL3546	Multi UMNL Connector 4 Pin Male	
21A	EL3540	Multi UMNL Connector 4 Pin Male	
22	EL3557	Pin For All UMNL Male Connectors	
23	EL3556	Pin For All Female UMNL Connectors	

FIG. 89 CONNECTORS AND TOOLS



KEY	PART CODE	DESCRIPTION	DIV
24	EL8136	Multi Connector 4 Pin Male	
24A	EL8134	Multi Connector 4 Pin Female	
25	EL8122	Multi Connector 2 Pin Male	
25A	EL8120	Multi Connector 2 Pin Female	
26	EL8130	Multi Connector 3 Pin Male	
26A	EL8128	Multi Connector 3 Pin Female	
27	EL8115	Cover Female Pins	
27A	EL8117	Cover Male Pins	
28	EL3126	Male Pins	
29	EL3110	Female Pins	

Hydraulic hoses 2045 Trend - 2060 Optimizer

1/4" Hydraulic hoses (1. lags Min: 250 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL4010	Drain L front engine.	45*	Drain Port PTO center.	90*	350	1
HYDSL4015	Drain R front engine.	45*	Drain port PTO bottom.	90*	400	1
HYDSL4020	Lift Cylinder lowering.	3/8 Banjo	Joystick block port B2	45*	500	1
HYDSL4025	Liftcylinder løft.	3/8 Banjo	Gas-acc T-stk.	90*	380	1
HYDSL4030	Gas-acc. T-stk.	90*	Contra and throttle valve cabin.	Straight	1500	1
HYDSL4035	Kontra/drøve ventil kabine.	Straight	Joystick block port A2	90*	1680	1
HYDSL4040	Joystick block port A3	90*	3/8 bulkhead front.	45*	750	1
HYDSL4045	Joystick block port B3	90*	3/8 bulkhead front.	45*	800	1
HYDSL4050	Joystick block port A4	45*	3/8 bulkhead front.	45*	860	1
HYDSL4055	Joystick block port B4	45*	3/8 bulkhead front.	45*	880	1
HYDSL4060	Drain H rear engine.	Straight	Return block rear.	90*	1750	1
HYDSL4065	Drain R rear engine.	90*	Return block rear.	90*	360	1
HYDSL4070	Steering cylinder.	90*	Orbitrol.	90*	720	1
HYDSL4075	Steering cylinder.	90*	Orbitrol.	90*	1020	1
HYDSL4080	Flush valve at the top.	Straight	Hydrostat.	90*	460	1
HYDSL4082	Flushing valve at the bottom.	Straight	Hydrostat.	90*	830	1
HYDSL4085	Flushing valve at the bottom.	Straight	T-piece drainage behind.	90*	300	1

3/8" Hydraulic hoses (1. lags Min: 250 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL5110	PTO block port T3.	Straight	1/2 bulkhead front.	45*	610	1
HYDSL5115	PTO block port T1.	Straight	Orbitrol.	90*	600	1
HYDSL5120	Joystick block port P	90*	Kubota single pump.	90*	1800	1
HYDSL5125	Return block by the radiator.	90*	3/8 bulkhead rear.	90*	420	1
HYDSL5130	Return block by the radiator.	90*	1/2 bulkhead front.	90*	190	1
HYDSL5135	Joystick block port A1.	45*	3/8 bulkhead rear.	90*	2200	1
HYDSL5140	Hydrostatic port D.	45*	Medium pressure filter 2045	90*	1540	1
HYDSL5145	Hydrostatic port E.	45*	Medium pressure filter 2045	90*	1520	1
HYDSL5150	PTO pump.	90*	Orbitrol port P 2045	90*	180	1
HYDSL5155	Hydrostatic Out.	90*	Medium pressure filter 2060	90*	185	1
HYDSL5160	Hydrostatic In.	90*	Medium pressure filter 2060	90*	1900	1
HYDSL5165	PTO pump.	Straight	Orbitrol port P 2060	90*	1950	1

Hydraulic hoses 2045 Trend - 2060 Optimizer

¾" Hydraulic hoses (2. lags Min: 300 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL6010	PTO - port A1.	Straight	3/4 - skot bag.	90*	2650	1
HYDSL6015	Wheel Motor LF.	45*	Wheel Motor LR	45*	1400	1
HYDSL6020	Wheel Motor RF.	45*	Wheel Motor RR.	45*	1420	1

Hydraulic hoses 2045 Trend

¾" Hydraulic hoses (2. lags Min: 300 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL6210	T-piece Hydrostat port A	45*	Wheel Motor LR	Straight	170	1
HYDSL6215	T-piece Hydrostat port B	45*	Wheel Motor RR.	Straight	820	1
HYDSL6220	T-piece Hydrostat port A	45*	Wheel Motor LF.	45*	1100	1
HYDSL6225	T-piece Hydrostat port A	45*	Wheel Motor RF.	45*	1680	1
HYDSL6230	PTO pump port P	90*	PTO block port P	90*	2250	1

Hydraulic hoses 2060 Optimizer

¾" Hydraulic hoses (2. lags Min: 300 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL6410	T-piece Hydrostat port A	Straight	Wheel Motor LR	Straight	300	1
HYDSL6415	T-piece Hydrostat port A	90*	Wheel Motor RR	Straight	710	1
HYDSL6420	T-piece under the Hydrostat	Straight	Wheel Motor RF.	45*	1170	1
HYDSL6425	T-piece under the Hydrostat	Straight	Wheel Motor LF.	45*	1190	1
HYDSL6430	PTO pumpe port P	Straight	PTO block port P	90*	2250	1

Part code	Page	Part code	Page
AC2526	58	BM5655	44
AC2530	59	BM5655	45
AC2531	59	BM6032	29
AC2532	59	BM6040	29
AC2538	59	BM6265	43
AC2541	59	BM8010	27
AC2545	59	BM8090	27
AC3020	59	BM8210	71
AC5020	58	BM8212	91
AC5022	58	BM9010	73
AC8040	58	BM9010	14
AC8041	58	BM9210	58
AC8042	59	BM9215	22
AC8043	59	BM9220	22
AC8044	59	BM9262	44
AC8045	59	BM9262	45
BM1110	35	BR1025	11
BM1118	35	BR1310	11
BM1118	70	BR1320	11
BM1250	73	BR1321	11
BM1838	78	BR1508	76
BM1870	27	BR1509	76
BM1960	31	BR1510	76
BM2001	48	BR1511	76
BM2020	35	BR1512	76
BM2020	67	BR1514	76
BM2020	71	BR1525	77
BM2051	78	BR2010	76
BM2345	46	BR2012	76
BM2347	46	BR2014	76
BM2515	48	BR2020	11
BM2531	67	DIV1025	67
BM2547	29	DIV1027	67
BM2620	67	DIV1030	67
BM2635	78	DIV1034	68
BM2670	27	DIV1036	68
BM2795	70	DIV1038	68
BM2805	36	DIV1040	68
BM2950	27	DIV1042	67
BM3002	48	DIV1044	68
BM3015	49	DIV10502	63
BM3015	71	DIV10503	64
BM3110	71	DIV10504	62
BM3505	70	DIV1051A	66
BM3530	60	DIV1052B	65
BM5207	11	DIV1054	69
BM5255	15	DIV1055	69
BM5255	15	DIV1059	73
BM5255	37	DIV1085	75
BM5410	79	DIV1525	49
BM5420	36	DIV1550	60

Part code	Page	Part code	Page
DIV2009	58	DIV5125	80
DIV2035	58	DIV6010	12
DIV2036	58	DIV6014	12
DIV2040	60	DIV6014	49
DIV2050	39	DIV6018	12
DIV2050	61	DIV6020	12
DIV2070	9	DIV6030	12
DIV2070	61	DIV8010	52
DIV2072	61	DIV8021	52
DIV2130	61	DIV8021	57
DIV2132	39	DIV8025	39
DIV2230	39	EL1010	48
DIV2240	41	EL1010	48
DIV2310	52	EL1018	48
DIV2312	52	EL1031	48
DIV2320	52	EL1057	91
DIV2330	52	EL1105	72
DIV2332	52	EL1115	48
DIV2335	53	EL1115	72
DIV2340	52	EL1119	92
DIV2342	52	EL1120	72
DIV2345	52	EL1130	72
DIV2350	52	EL1148	72
DIV2360	52	EL1149	72
DIV2370	52	EL1157	48
DIV2380	52	EL1167	72
DIV2385	52	EL1168	72
DIV2385	52	EL1170	48
DIV2390	52	EL1170	72
DIV3058	48	EL1185	48
DIV3070	48	EL1185	72
DIV41	10	EL1312	14
DIV41	10	EL2000	90
DIV4109	74	EL2002	90
DIV4115	74	EL2005	90
DIV4117	10	EL2007	90
DIV4128	10	EL2008	90
DIV4117A	10	EL2020	90
DIV4128	11	EL2021	90
DIV4140	10	EL2076	72
DIV4147	10	EL2089	72
DIV4147	11	EL2092	72
DIV4154	73	EL2093	72
DIV4310	39	EL2166	72
DIV5010	80	EL2167	72
DIV5046	80	EL2215	72
DIV5049	80	EL2519A	34
DIV5050	80	EL2520	47
DIV5120	39	EL2525	42
DIV5120	80	EL2540	50
DIV5125	39	EL2540	51

Part code	Page	Part code	Page
EL2544	90	EL8550	91
EL3110	94	EL9007	81
EL3126	94	EL9015A	89
EL3310	91	EL9018	23
EL3312	91	EL9020	84
EL3505	93	EL9036	87
EL3512	93	EL9037	77
EL3514	92	EL9048	89
EL3514	93	EL9065	86
EL3525	93	EL9108	82
EL3527	93	EL9109	88
EL3530	93	EL9113	83
EL3532	93	EL9114	83
EL3540	93	EL9122	85
EL3540	93	EL9125	49
EL3541	93	EL9152	47
EL3542	93	EL9168	77
EL3546	93	EL9169	77
EL3547	93	EL9200	48
EL3550	93	EL9215	91
EL3555	93	EL9220	90
EL3556	93	EL9222	90
EL3557	93	EL9223	88
EL4010	48	FI1350	22
EL4010	92	FI1410	21
EL4014	51	FI1410	22
EL4020	48	FI1420	21
EL4020	51	FI1420	22
EL4020	92	FI1525	34
EL4022	92	FI1530	34
EL8110	92	FS4049	72
EL8115	94	FS4210	39
EL8117	94	FS6415	73
EL8120	94	FS6500	39
EL8122	94	FS6718	37
EL8128	94	FSB415	37
EL8130	94	GF2025	79
EL8134	94	GF2060	39
EL8136	94	GF2065	39
EL8137	88	GF2072	39
EL8158	92	GF2074	39
EL8159	92	GF2076	39
EL8160	92	GL1510	54
EL8161	92	GL1514	54
EL8165	92	GL1518	55
EL8167	92	GL1524	55
EL8180	92	GL1528	56
EL8182	92	GL1535	56
EL8190	92	GL2010	53
EL8510	48	GL2010	74
EL8546	91	GL2020	53

Part code	Page	Part code	Page
GL2025	52	HYD1166	16
GU1012	70	HYD1169	16
GU1026	70	HYD1172	16
GU1040	40	HYD1175	16
GU1045	79	HYD1360	17
GU1105	14	HYD1365	17
GU1116	70	HYD1368	17
GU2110	58	HYD1371	17
GU2118	42	HYD1374	17
GU2132	42	HYD1377	17
GU3008	78	HYD1380	17
GU3013	31	HYD1552	19
GU3016	78	HYD1560	20
GU3020	44	HYD1565	20
GU3510	26	HYD1660	20
GU3515	26	HYD1730	11
GU3525	26	HYD1730	15
GU4004	77	HYD1740	15
GU4010	36	HYD1744	15
GU4510	26	HYD1748	15
GU4530	26	HYD1752	15
GU4532	26	HYD1855	23
GU4557	25	HYD1910	21
GU4559	25	HYD1912	9
GU4560	25	HYD1920	21
GU4560	25	HYD1922	9
GU4562	25	HYD1925	21
GU4564	25	HYD1927	9
GU4570	25	HYD1950	21
GU4624	21	HYD1987	23
GU5020	59	HYD2220	23
GU5021	34	HYD2222	23
GU5023	31	HYD2224	23
GU5025	14	HYD2226	23
GU5110	24	HYD2227	23
GU5150	70	HYD2228	23
GU6012	53	HYD2230	23
GU6022	41	HYD2232	23
GU6027	59	HYD2316	19
GU6069	79	HYD2317	19
GU6070	59	HYD2317	24
GU6070	70	HYD2317A	24
GU6072	70	HYD2317B	19
GU6650	39	HYD2317B	24
HJ1033	13	HYD2322	24
HJ1037	13	HYD2325	19
HJ5150	11	HYD2325	24
HJ5150	13	HYD4001	25
HYD1150	16	HYD4004	25
HYD1160	16	HYD4004	26
HYD1163	16	HYD4007	26

Part code	Page	Part code	Page
HYD4010	25	HYDSL4020	95
HYD4014	25	HYDSL4025	95
HYD4018	25	HYDSL4030	95
HYD4019	25	HYDSL4035	95
HYD4046	26	HYDSL4040	95
HYD4048	26	HYDSL4045	95
HYD4050	26	HYDSL4050	95
HYD4054	26	HYDSL4055	95
HYD4705	76	HYDSL4060	95
HYD4710	15	HYDSL4065	95
HYD4723	15	HYDSL4070	95
HYD4745	15	HYDSL4075	95
HYD4746	15	HYDSL4080	95
HYD4780	83	HYDSL4082	95
HYD4802	11	HYDSL4085	95
HYD4827	18	HYDSL5110	95
HYD4847	76	HYDSL5115	95
HYD4948	77	HYDSL5120	95
HYD4960	21	HYDSL5125	95
HYD5044	18	HYDSL5130	95
HYD5044	18	HYDSL5135	95
HYD5054	25	HYDSL5140	95
HYD5054	26	HYDSL5145	95
HYD5058	25	HYDSL5150	95
HYD5058	26	HYDSL5155	95
HYD5060	25	HYDSL5160	95
HYD5060	26	HYDSL5165	95
HYD5102	58	HYDSL6010	96
HYD5310	15	HYDSL6015	96
HYD5314	25	HYDSL6020	96
HYD5314	26	HYDSL6210	96
HYD5318	25	HYDSL6215	96
HYD5318	26	HYDSL6220	96
HYD5322	15	HYDSL6225	96
HYD5322	25	HYDSL6230	96
HYD5322	26	HYDSL6410	96
HYD5340	18	HYDSL6415	96
HYD5410	21	HYDSL6420	96
HYD5415	76	HYDSL6425	96
HYD5513	18	HYDSL6430	96
HYD5514	18	HYP1090	20
HYD5517	18	HYP2020	20
HYD5520	18	HYP2040	20
HYD7069	22	KØ1075	40
HYD7070	22	KØ2020	40
HYD7120	22	KØ5010	9
HYD9153	16	KØ5070	9
HYD9153	17	KØ9010	21
HYDR2018	18	KØ9010	40
HYDSL4010	95	LS12113	73
HYDSL4015	95	LS9508	72

Part code	Page	Part code	Page
LS9510	72	RAT3075	50
LS9804	71	ST	73
LS9808	71	ST1070	11
LS9813	67	ST1079	19
MOT1065	42	ST1115	29
MOT2047	43	ST1117B	29
MOT2080	43	ST1119	29
MOT2082	9	ST1120	73
MOT2082	43	ST1127	29
MOT2085	43	ST1135	29
MOT9003	46	ST1140	29
MOT9007	46	ST1188	73
MOT9040	46	ST1510	27
MOT9045	46	ST2533	34
MOTC1520	9	ST2555	41
MOTC1530	9	ST2574	18
MOTC1552	34	ST3018	35
MOTC5018	44	ST3018	35
MOTC5018	45	ST3020	45
MOTC5025	44	ST3022	35
MOTC5025	45	ST3023	35
MOTC5035	44	ST3027B	29
MOTC5036	45	ST3031A	34
MOTC5038	44	ST3032B	34
MOTC5038	45	ST3034	32
MOTC6009	42	ST3036	32
MOTC6050	42	ST3037	32
MOTC6100	42	ST3044A	19
MOTC6110	42	ST3045	23
MOTC6540	42	ST3047B	31
RAT	50	ST3053	73
RAT	50	ST3056	31
RAT1020	47	ST3058	31
RAT3001	50	ST3059	28
RAT3003	51	ST3060	28
RAT3003	51	ST3065B	41
RAT3004	51	ST3070	33
RAT3005	47	ST3072G	44
RAT3006	47	ST3072G	45
RAT3010	51	ST3072H	44
RAT3020	50	ST3072H	45
RAT3021	50	ST3075	91
RAT3030	50	ST30914	70
RAT3040	51	ST3095A	70
RAT3044	51	ST3098	52
RAT3046	51	ST3101	34
RAT3050	50	ST3115	37
RAT3054	50	ST3126	21
RAT3056	50	ST3127	21
RAT3058	50	ST3143	31
RAT3070	50	ST3211	53

Part code	Page	Part code	Page
ST3215	53	ST9135	69
ST3219	53	ST9140	33
ST3222	53	ST9430	15
ST3227	53	ST9435	15
ST3230	53	STL1057	27
ST3238	53	STL2204	72
ST3245	48	VI2030	57
ST3271	74	VI2097	57
ST3272	74	VI4010	57
ST3273	74	VI4011	57
ST3274	74	VI4012	57
ST3312	19	VI4013	57
ST3322	19	VÆ7010	92
ST3336	29	VÆ7012	92
ST3349	29	VÆ7015	92
ST3379	14		
ST3405	18		
ST3413	21		
ST3414	21		
ST3510	67		
ST3550	37		
ST3551	31		
ST3555	37		
ST3560	37		
ST3565	39		
ST3565	39		
ST3570	39		
ST3580	79		
ST3582	79		
ST3585	73		
ST3590	73		
ST3595	73		
ST3810	27		
ST4010	27		
ST4100	27		
ST4210	24		
ST4210	27		
ST4265	24		
ST7011	21		
ST7018	34		
ST7021B	34		
ST7028	34		
ST9016	73		
ST9020	14		
ST9022	14		
ST9033	44		
ST9033	45		
ST9115	27		
ST9117	27		
ST9133	74		
ST9134	74		

Specifications subject to change.

We reserve the right to make changes to the machine without at the same time these instructions are change.



Producent:
Lindholdt Maskiner A/S
6818 Årre DK.