

PARTS CATALOG



SWEEPING SUCTION MACHINE

Ver: 1.8

Indeks

Symboler

1/2 Tredoring 27
1/4 Tredoring 27
3 pole plug 35
6mm Locknut 6
6 Way Valve 8
7 pole plug 35
8mm Flat Washer 6
12mm Bushing 6
12mm facet washer 25
12mm Flat Washer 6, 8
12mm Locknut 6, 8
12x25 Recessed FZB 25
12x25 Unbraco 25

A

Adapter 21
Adapter Horn 26
Adjust cap for the suction head 13
Adjust front wheel 6
A-frame she cat 0 7
A-frame she cat 1 7
Angle piece 9
Arm to motor 11
Axel 18

B

Bearing 11, 34
Bearing for suction head 12
Big wheel for suction head 13
Bolt 24
Bolt brush 8x170 14
Bolt for end cover 13
Bottom Frame 28
Bottom Frame suction box 18
Bracket 13
Bracket 1 front wheel 6
Bracket 2 front wheel 6
Bracket for hydraulic motor 15
Bracket for Rear coupling (Unit) 24
Bracket front wheel 6
Bracket plate for Rear coupling (Unit) 24
Brush 14
Bush 11, 14

C

Center bracket 8
Centre coupling suction Wing 16
Centre section front 7
Clamping fittings 27
Clips 21
Console arm Left 11
Console arm Right 11
Console for arm 11
Coupling for suction tube Rear 23
Coupling rear 25
Cover plate behind 29

Cover plate under cab 24
Cover suction wing new 32
Cover suction wing old 32
Cyclone House 17
Cylinder for sweep arms 34
Cylinder for tip 34

D

Door suction box 18
Drain pipe 27
Drain pipe 2 27

E

End cover for suction head 13
External hose clamp 21
External suction compleat 20
External suction head 20, 21
External suction head holder 21
External suction hose 20

F

Filling water tank 22
Flat Washer 8,4x25x2 11
Front Bracket 8

G

Gasket for external suction head 20, 33
Guide plate horn 25

H

Handle for external suction hose 20
Handle front wheel 6
Hatch 18
Hatch mounting 24
Hatch rear coupling 24
Hinge 26
Horn tap 4mm 23
Horn tap 5mm 23
Hose Clamp 10, 12, 17, 20, 22, 23, 25, 31
Hose Extern 31
Hose Extern new 31
Hose Front 31
Hose protection 28
Hose Tank 31
Hose Under Cabin 31
Hydraulic motor 14 cc 15
Hydraulic motor 17 cc 15

L

Large rubber strip for Door 33
Lid for external suction hose 20
Lock 26
Lock bottom frame 28
Lock Clips 23
Lock plate 25
Lock plate 4mm 23
Lock plate 5mm 23
Look Suction hose coupling 10
Lower arm 11

M

M5 Flat Washer 8, 10, 24
M5 Locknut 8, 10
M5x10 Bottonhead 10
M5x16 Unbraco 8
M6 Flat Washer 24, 27
M6 Spring Washer 24
M6x10 24
M6x25 27
M6x35 27
M6x40 Bolt 6
M8 Flat Washer 8
M8 Locknut 8, 24
M8 Spring washer 8
M8x16 11
M8x20 8
M8x20 Bolt 8
M8x50 8
M8x50 Bolt 6
M10 Flat Washer 13
M10 Spring Washer 13
M10x20 13
M12 Flat Washer 11, 13, 23
M12 Locknut 11
M12 Spring Washer 13
M12x25 Unbraco 23
M12x30 Unbraco 13
M12x35 23
M12x45 8
M12x45 Unbraco 11
M12x90 6
M14 Flat Washer 15
M14 Locknut 15
M14x35 15
Motor bracket 8
Mount for suction head 8
Mounting plate side Brush 30

N

Nagle 11, 34
Nippel 8, 9, 27
No return valve 15
Nozzle Mount long 9
Nozzle Mount small 9
Nut 26
Nut for front horn 25

O

Oil pipe Left 27
Oil pipe Right 27
OMP 50 motor 14
OMP 100 motor 14
OMP 160 motor 11
O-ring 23, 24, 34
O-ring seal 25
Overload valve 15
Overload valve blok 15

P

Pipe holder 27
Plate suction box 19

R

Radiator grille 26
Rear coupling (Unit) 24
Rem 22
Ring Split 25
Rubber cover suction wing 33
Rubber List 21
Rubber list cyclonic House 17, 33
Rubber list door suction box 18
Rubber Lock 20
Rubber Mount 24

S

Screw for cover 29
Seal kit hydraulic motor 15
Shaft 21
Shaft tap 15
Side Brush 30
Small rubber strip for Door 33
Small wheel for suction head 13
Spindle Ex. Fork and Wheel 6
Spindle front wheel 6
Spring 24
Spring for external suction head 20
Spring for Rear coupling (Unit) 24
Sticker 18
Suction box 18
Suction Head 12
Suction hose coupling 10
Suction hose Rear 22
Suction Wing 16
Swivel 1/2 27
Swivel 1/4 27
Swivel holder 27
Swivel wheel for trolley 29

T

Tap to the front horn 25
Tee piece 9
Trolley for sweep suction 2030/2040 29
Trolley for sweep suction 2045 29
Trolley for sweep suction 2060 29

U

Upper arm Left 11
Upper arm Right 11

V

Valve Connector 8

W


Water Filter 9
Water line 8 mm 9
Water Nozzle 9
Water Pump 9
Water Tank Left 22
Water Tank Right 22
Wheel fork 6
Wheel for trolley 29

FIG. 1 FRONT SUPPORT WHEEL




KEY	PART CODE	DESCRIPTION	DIV.
1	FS7410	Adjust front wheel	
2	FS7402	Wheel fork	
3	FS7403	Spindle Ex. Fork and Wheel	
4	FS7403A	Spindle front wheel	
5	FS7403B	Handle front wheel	
6	FS7404	Bracket front wheel	
7	BM2011	6mm Locknut	
8	BM1138	M6x40 Bolt	
9	FSF510	Bracket 1 front wheel	
10	FSA59	Bracket 2 front wheel	
11	BM1350	M8x50 Bolt	
12	BM2620	8mm Flat Washer	
13	BM2041	12mm Locknut	
14	BM2630	12mm Flat Washer	
15	FS7415	12mm Bushing	
16	BM1642	M12x90	

FIG. 2 CENTRE SECTION FRONT




KEY	PART CODE	DESCRIPTION	DIV.
1	FSA38	Centre section front	
2	ST4022	A-frame she cat 0	
3	ST4025	A-frame she cat 1	

FIG. 3 PARTS SECTION FRONT



KEY	PART CODE	DESCRIPTION	DIV.
1	FSF54	Motor bracket	
2	FSF29	Center bracket	
3	BM1322	M8x20 Bolt	
3a	BM2730	M8 Spring washer	
3b	BM2620	M8 Flat Washer	
4	BM1734	M12x45	
4a	BM2540	12mm Flat Washer	
4b	BM2041	12mm Locknut	
5	FSF2131	Front Bracket	
6	BM5340	M5x16 Unbraco	
6a	BM2610	M5 Flat Washer	
6b	BM2006	M5 Locknut	
7	BM1322	M8x20	
7a	BM2730	M8 Spring washer	
7b	BM2021	M8 Locknut	
8	FSA58	Mount for suction head	
9	BM1350	M8x50	
9a	BM2620	M8 Flat Washer	
10	HYD4715	Nippel (10a HYD5314)	
11	HYD9810	6 Way Valve	
12	HYD2250	Valve Connector	


FIG. 4 WATER PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	MOT9141	Water Filter	
2	BM5335	Hose Clamp	
3	FS4090	Tee piece	
4	HYD4715	Nippel	
5	FS5014	Nozzle Mount long	
6	FS5010	Nozzle Mount small	
7	FS4107	Nippel	
8	FS4086	Angle piece	
9	FS4050	Water Nozzle	
10	FS4080	Nippel	
11	FS8012	Water Pump	
12	FS1710	Water line 8 mm	1 Meter




FIG. 5 SUCTION HOSE PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	FS7386	Suction hose coupling	
2	FS1690	Hose Clamp	
3	DIV2112	Look Suction hose coupling	
3a	BM5397	M5x10 Bottom head	
3b	BM2610	M5 Flat Washer	
3c	BM2006	M5 Locknut	
4	FS7385	Suctionhose coupling - Chassis	

FIG. 6 ARM PARTS SECTION FRONT




KEY	PART CODE	DESCRIPTION	DIV.
1	FS2010	OMP 160 motor	
2	FSF86	Arm to motor	
3L	FSF80L	Upper arm Left	
3R	FSF80R	Upper arm Right	
4	FSF82	Lower arm	
5L	FSF81L	Console arm Left	
5R	FSF81R	Console arm Right	
6	BM1318	M8x16	
6a	BM2810	Flat Washer 8,4x25x2	
6b	ST9021	Bearing	
7	BM5250	M12x45 Unbraco	
7a	BM2630	M12 Flat Washer	
7b	BM2041	M12 Locknut	
8	FS6410	Bush	
9	FS6730	Nagle	
10	FS6405	Bush	
11	FS6415	Bush	
12	FS6720	Nagle	
13	FSF2131	Console for arm	

FIG. 7 SUCTION HEAD




KEY	PART CODE	DESCRIPTION	DIV.
1	FS7010	Suction Head	
2	HYD2350	Bearing for suction head	
3	FS1690	Hose Clamp	

FIG. 8 PARTS SUCTION HEAD




KEY	PART CODE	DESCRIPTION	DIV.
1	FSF27	End cover for suction head	
2	FSF84	Adjust cap for the suction head	
3	FS7407	Big wheel for suction head	
4	FS7405	Small wheel for suction head	
5	BM5402	Bolt for end cover	
6	BM1518	M10x20	
6a	BM2735	M10 Spring Washer	
6b	BM2625	M10 Flat Washer	
7	BM5250	M12x30 Unbraco	
7a	BM2740	M12 Spring Washer	
7b	BM2630	M12 Flat Washer	
8	BM1518	M10x20	
8a	BM2735	M10 Spring Washer	
8b	BM2625	M10 Flat Washer	
9	FSA58	Bracket	

FIG. 9 PARTS SUCTION HEAD



KEY	PART CODE	DESCRIPTION	DIV.
1	FS2015	OMP 100 motor	
1A	FS2014	OMP 50 motor	
2	FS1530	Brush	
3	FS6505	Bush	
4	BM1276	Bolt brush 8x170	
5	FS6510	Bush	

FIG. 10 SUCTION HYDRAULIC MOTOR



KEY	PART CODE	DESCRIPTION	DIV.
1	FSA49	Bracket for hydraulic motor	
2	FS2020	Hydraulic motor 14 cc	
2a	FS2019	Hydraulic motor 17 cc	
3	FS2025	Shaft tap	
4	BM2635	M14 Flat Washer	
4a	BM2051	M14 Locknut	
4b	BM1918	M14x35	
5	FS2715	No return valve	
6	FS2710	Overload valve	
7	FS2712	Overload valve blok	
8	FS2021	Seal kit hydraulic motor	






FIG. 11 SUCTION WING




KEY	PART CODE	DESCRIPTION	DIV.
1	FS1450	Suction Wing	
2	FS1452	Centre coupling suction Wing	

FIG. 12 CYCLONE HOUSE




KEY	PART CODE	DESCRIPTION	DIV.
1	FSA24	Cyclone House	
2	GU6070	Rubber list cyclonic House	
3	BM9249	Hose Clamp	

FIG. 13 SUCTION BOX




KEY	PART CODE	DESCRIPTION	DIV.
1	FS1037	Hatch	
2	DIV5052	Sticker	
3	FS1035	Door suction box	
4	FS8211	Rubber list door suction box	
5	FSA310	Bottom Frame suction box	
6	FS1010	Suction box	
7	FS6723	Axel	

FIG. 14 SUCTION BOX



KEY	PART CODE	DESCRIPTION	DIV.
1	FS1045	Plate suction box	

FIG. 15 EXTERNAL SUCTION HOSE



KEY	PART CODE	DESCRIPTION	DIV.
1	FS9650	External suction head	
2	FS1600	External suction hose	
3	FSA23	Lid for external suction hose	
4	GU4090	Gasket for external suction head	
5	ST9015	Spring for external suction head	
6	BM9249	Hose Clamp	
7	FS5556	Handle for external suction hose	
8	DIV8038	Rubber Lock	
9	FEG1120	External suction compleat	






FIG. 16 EXTERNAL SUCTION HOSE



KEY	PART CODE	DESCRIPTION	DIV.
1	FS9651	External hose clamp	
2	FS9652	External suction head holder	
3	FS7510	Shaft	
4	FS7515	Adapter	
5	FS9653	External suction head	
6	FS9665	Clips	
7	GU6025	Rubber List	


ALL PARTS USED BY FRAME NO. 077

FIG. 17 WATER TANK




KEY	PART CODE	DESCRIPTION	DIV.
1L	FS1020	Water Tank Left	
1R	FS1025	Water Tank Right	
2	FS8050	Filling water tank	
3	FS1609	Suction hose Rear	
4	FS1695	Rem	
5	FS1690	Hose Clamp	

FIG. 18 PARTS SUCTION TUBE




KEY	PART CODE	DESCRIPTION	DIV.
1	FSA52	Coupling for suction tube Rear	
2	BM5242	M12x25 Unbraco	
2a	BM2630	M12 Flat Washer	
3	FS6712	Horn tap 4mm	
3a	FS6710	Horn tap 5mm	
4	BM1726	M12x35	
4a	BM2630	M12 Flat Washer	
5	FSB414	Lock plate 4mm	
5a	FSB53	Lock plate 5mm	
6	ST9118	Lock Clips	
7	FS8220	O-ring	
8	FS1690	Hose Clamp	

FIG. 19 PARTS SUCTION TUBE




KEY	PART CODE	DESCRIPTION	DIV.
1	FSA211	Rear coupling (Unit)	
2	BM1110	M6x10	
2a	BM2615	M6 Flat Washer	
2b	BM2725	M6 Spring Washer	
3	FSA319	Hatch rear coupling	
4	FSB37	Hatch mounting	
5	BM5650	Bolt	
5a	ST90281	Spring	
5b	BM2610	M5 Flat Washer	
6	ST9016	Spring for Rear coupling (Unit)	
7	BM2021	M8 Locknut	
8	GU3013A	Rubber Mount	
9	BM5340	Bolt	
10	FSB36	Bracket for Rear coupling (Unit)	
11	FSB218	Bracket plate for Rear coupling (Unit)	
12	FS8220	O-ring	
13	FSF1.5	Cover plate under cab	
14			

FIG. 18 PARTS SUCTION TUBE




KEY	PART CODE	DESCRIPTION	DIV.
1	ST3552	Guide plate horn	
2	BM5242	12x25 Unbraco	
2A	BM2630	12mm facet washer	
2B	BM5379	12x25 Recessed FZB	
3	FS6718	Tap to the front horn	
3A	FS6716	Nut for front horn	
4	FSA54	Coupling rear	
5	FS1690	Hose Clamp	
6	FSB415	Lock plate	
7	ST9118	Ring Split	
8	FS8220	O-ring seal	

FIG. 19 PARTS SUCTION TUBE




KEY	PART CODE	DESCRIPTION	DIV.
1	FSA130	Adapter Horn	
2	FS7370	Lock	
2a	HYD5059	Nut	
3	ST3065B	Radiator grille	
4	DIV2240	Hinge	
5			

FIG. 20 HYDRAULIC PIPES



KEY	PART CODE	DESCRIPTION	DIV.
1L	FS1855	Oil pipe Left	
1R	FS1850	Oil pipe Right	
2	FS1860	Drain pipe	
2a	FS1870	Drain pipe 2	
3	BM2615	M6 Flat Washer	
3a	BM1134	M6x35	
3b	HYD4785	Pipe holder	
4	BM2615	M6 Flat Washer	
4a	BM1126	M6x25	
4b	HYD4780	Pipe holder	
5	FSB226	Swivel holder	
6	FS2810	Swivel 1/2	
7	FS2814	Swivel 1/4	
8	HYD4755	Clamping fittings	
9	HYD4750	Clamping fittings	
10	HYD4724	Nippel	
11	HYD4710	Nippel	
12	HYD5310	1/4 Tredoring	
12a	HYD5318	1/2 Tredoring	


FIG. 20 BOTTOM FRAME



KEY	PART CODE	DESCRIPTION	DIV.
1	FSA121	Bottom Frame	
2	FS7370	Lock bottom frame	
3	FSB230	Hose protection	



FIG. 21 TROLLEY FOR SWEEP SUCTION








KEY	PART CODE	DESCRIPTION	DIV.
1	FSB231	Cover plate behind	
2	DIV2130	Screw for cover	
3	FEG1060	Trolley for sweep suction 2030/2040	
3a	FEG1061	Trolley for sweep suction 2045	
3b	FEG1062	Trolley for sweep suction 2060	
4	FS7420	Swivel wheel for trolley	
5	FS7426	Wheel for trolley	

FIG. 22 FRONT SWEEPER




KEY	PART CODE	DESCRIPTION	DIV.
1	FS1510	Side Brush	
2	FSA36	Mounting plate side Brush	

FIG. 23 HOSE




KEY	PART CODE	DESCRIPTION	DIV.
1	FS1605	Hose Front	
2	FS1607	Hose Under Cabin	
3	FS1609	Hose Tank	
4	FS1600	Hose Extern	
5	FS1603	Hose Extern new	
6	BM9249	Hose Clamp	
7	FS1690	Hose Clamp	

FIG. 24 COVER SUCTION WING




KEY	PART CODE	DESCRIPTION	DIV.
1	FSB213	Cover suction wing old	
2	FS1048	Cover suction wing new	

FIG. 25 RUBBER PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	FS8210	Large rubber strip for Door	
2	FS8215	Small rubber strip for Door	
3	GU6070	Rubber list cyclonic House	
4	GU6510	Rubber cover suction wing	
5	GU4090	Gasket for external suction head	

FIG. 26 CYLINDER



KEY	PART CODE	DESCRIPTION	DIV.
1	FS2520	Cylinder for sweep arms	
2	HYD2350	Bearing	
3	FS2530	Cylinder for tip	
4	HYD2315A	Bearing	
5	FS6722	Nagle	
6	FS8230	O-ring	

FIG. 27 ELECTRICAL PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	EL2546	7 pole plug	
2	EL2552	3 pole plug	

FIG. 81 HYD. HOSE LISTING FS 1010

The hoses written in red is for Optimizer and Trend models

1/4" HYD HOSE LISTING FRONT-UNIT FS 1010 (1. lags Min: 200 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
FS1910	Right engine inside	Straight	Balancing valve port: Reg	90*	450	1
FS1914	Top Right engine inside	Straight	Left engine inside top	Straight	480	1
FS1916	Quick couplings motor function chassis	Straight	Motor roller brush top	45*	144	1
FS1918	Left engine inside bottom	Straight	Balancing valve port: T-T-stk	Straight	740	1
FS1926	Bulkhead at the bottom right inside the front	90*	Motor roller brush top	45*	560	1
FS1936	Bulkhead left outer front	45*	Quick couplings left at cabin	Straight	400	2
FS1939	Bulkhead middle exterior front	45*	Quick couplings right at cabin	Straight	400	2
FS1930	Motor roller brush bottom	45*	Balancing valve port: P	90*	660	1
FS1934	Bulkhead left outer front	90*	Quick couplings left at cabin	Straight	320	2
FS1938	Bulkhead middle exterior front	90*	Quick couplings inside on the left of the cabin	Straight	320	1
FS1944	Left engine inside bottom	Straight	Parallel arm right bottom	Straight	1200	1
FS1946	Parallel arm right at the top	Straight	Parallel arm left at the top	Straight	1940	1
FS1949	Parallel arm left bottom	Straight	Quick couplings left at cabin	90*	1170	1
FS1951	Cylinder to swing inside R/L	90*	Bulkhead left inner Bulkhead right middle inner	90*	350	2
FS1951A	Cylinder to swing the outer R/L	90*	Bulkhead left middle inner Bulkhead right top inner	90*	440	2
FS1948	Parallel arm left bottom	Straight	Balancing valve port: T-T-stk	90*	1170	1
FS1950	Cylinder to swing inside R/L	90*	6-way valve at the front on the side	90*	140	2
FS1952	Cylinder to swing the outer R/L	90*	6-way valve at the rear on the side	90*	220	2
FS1953	Bulkhead middle left inside	90*	6-way valve on the bottom	Straight	240	1
FS1955	Bulkhead bottom left inside	90*	6-way valve on the top	Straight	280	1
FS1957	Bulkhead bottom right outer	90*	Water coupling on cabin	Straight	380	1

FIG. 81 HYD. HOSE LISTING UNIT FS 1010

The hoses written in red is for Optimizer and Trend models

1/4" HYD HOSE LISTING REAR-UNIT FS 1010 (1. lags Min: 200 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
FS1954	Lifting cylinder R / L bottom	45*	T-piece top	Straight	270	2
FS1956	Lifting cylinder R / L top	Banjo	T-piece bottom	Straight	590	2
FS1959	Couplings manœuvre back top	Straight	T-piece top	90*	520	1
FS1961	Couplings back bottom	Straight	T-piece bottom	90*	560	1
FS1963	Drain Coupling rear	Straight	1/4 Swivel	90*	650	1
FS1958	Couplings manœuvre back top	Straight	T-piece top	90*	370	1
FS1960	Couplings back bottom	Straight	T-piece bottom	90*	380	1
FS1962	Drain Coupling rear bottom	Straight	1/4 Swivel	90*	780	1
FS1964	1/4 Swivel	Straight	Hydraulic pipes under tank	90*	1050	2
FS1966	Hydraulic pipes	Straight	Bulkhead cyclone	90*	750	1
FS1942	Bulkhead cyclone	Straight	Drain blower motor	90*	570	1

3/8" HYD HOSE LISTING FRONT UNIT FS 1010 (1. lags Min: 200 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
FS1970	Bulkhead top inside	90*	Flow control valve port T	90*	300	1
FS1973	Bulkhead top inside	90*	Coupling drain on cabin	Straight	350	1
FS1971	Bulkhead top outside	45*	Coupling drain on cabin	Straight	380	1

3/8" HYD HOSE LISTING REAR UNIT (1. lags Min: 200 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
FS1980	Blower Motor Port: T	90*	Check valve	Straight	130	1
FS1982	Check valve	90*	Blower Motor Port: P	90*	190	1
FS1983	Blower Motor Port: T	90*	Soft start valve gate: 2	Straight	350	1
FS1984	Blower Motor Port: P	90*	Soft start valve gate: 1	Straight	90	1

1/2" HYD HOSE LISTING REAR UNIT (1. lags Min: 200 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
FS1990	Bulkhead on cyclone	Straight	Blower Motor Port: T	Straight	280	2
FS1992	Swivel	Straight	PTO rear lower	Straight	800	1
FS1994	Swivel	Straight	PTO rear top	Straight	600	1
FS1991	Swivel	Straight	PTO rear lower	Straight	950	
FS1993	Swivel	Straight	PTO rear top	Straight	660	
FS1997	Bulkhead on cyclone P	90*	Hydraulic piping suction box	Straight	410	1xxx
FS1998	Bulkhead on cyclone T	90*	Hydraulic piping suction box	Straight	370	1xxx
FS1999	Swivel R/L	90*	Hydraulic piping suction box	Straight	800	2xxx

JOYSTICK 1/4" HYD HOSE LISTING FRONT-UNIT FS 1010 (1. lags Min: 200 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
FS1914	Top Right engine inside	Straight	Left engine inside top	Straight	480	1
FS1926	Bulkhead at the bottom right inside the front	90*	Motor roller brush top	45*	560	1
FS1934	Bulkhead left outer front	90*	Quick couplings left at cabin	Straight	320	2
FS1938	Bulkhead middle exterior front	90*	Quick couplings inside on the left of the cabin	Straight	320	1
FS1944	Left engine inside bottom	Straight	Parallel arm right bottom	Straight	1200	1
FS1946	Parallel arm right at the top	Straight	Parallel arm left at the top	Straight	1940	1
FS1950	Cylinder to swing inside R/L	90*	6-way valve at the front on the side	90*	140	2
FS1952	Cylinder to swing the outer R/L	90*	6-way valve at the rear on the side	90*	220	2
FS1953	Bulkhead middle left inside	90*	6-way valve on the bottom	Straight	240	1
FS1955	Bulkhead bottom left inside	90*	6-way valve on the top	Straight	280	1
FS1957	Bulkhead bottom right outer	90*	Water coupling on cabin	Straight	380	1

JOYSTICK 3/8" HYD HOSE LISTING FRONT UNIT FS 1010 (1. lags Min: 200 bar.)						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
FS1970	Bulkhead top inside	90*	Flow control valve port T	90*	300	1
FS1974	Motor roller brush bottom	45*	Motor side brush bottom	Straight	640	1
FS1975	Motor side brush R top	Straight	Bulkhead L top	90*	1150	1
FS1976	Motor side brush L bottom	Straight	Bulkhead L top	90*	380	1
1/4" HYD HOSE LISTING FOR THE 2 PROTOTYPE						
FS1986	Bulkhead L bottom	90*	Cyl. swing L +	90*	350	1
FS1987	Bulkhead L In the middle	90*	Cyl. swing L -	90*	440	1
FS1988	Bulkhead R bottom	90*	Cyl. swing R +	90*	350	1
FS1989	Bulkhead R In the middle	90*	Cyl. swing R -	90*	440	1
FS1989A	Bulkhead L top	90*	Arm L bottom	Straight	1110	1

Part code	Page	Part code	Page
BM1110	23	BM5340	8
BM1126	24	BM5340	23
BM1134	24	BM5397	10
BM1138	6	BM5402	13
BM1276	14	BM5650	23
BM1318	11	BM9246	20
BM1322	8	DIV2112	10
BM1324	13	DIV2130	26
BM1350	6	DIV5052	18
BM1350	8	DIV8038	20
BM1518	13	EL2546	32
BM1642	6	EL2552	35
BM1726	22	EL8122	32
BM1734	8	FEG1060	26
BM1918	15	FS1010	18
BM2006	8	FS1020	21
BM2006	10	FS1025	21
BM2011	6	FS1035	18
BM2021	8	FS1037	18
BM2021	23	FS1045	19
BM2041	6	FS1450	16
BM2041	8	FS1452	16
BM2041	11	FS1510	27
BM2051	15	FS1530	14
BM2402	18	FS1600	28
BM2540	8	FS1605	28
BM2610	8	FS1607	31
BM2610	10	FS1609	21
BM2610	18	FS1609	28
BM2610	23	FS1630	20
BM2615	23	FS1690	10
BM2615	24	FS1690	12
BM2620	6	FS1695	21
BM2620	8	FS1710	9
BM2620	13	FS1850	24
BM2625	13	FS1855	24
BM2630	6	FS1860	24
BM2630	11	FS1910	33
BM2630	13	FS1914	33
BM2630	22	FS1918	33
BM2635	15	FS1926	33
BM2725	23	FS1930	33
BM2730	8	FS1934	33
BM2730	8	FS1938	33
BM2735	13	FS1942	33
BM2740	13	FS1944	33
BM2810	11	FS1946	33
BM5242	22	FS1948	33
BM5250	11	FS1950	33
BM5250	13	FS1952	33
BM5335	9	FS1953	33

Part code	Page	Part code	Page
FS1954	33	FS6722	31
FS1955	33	FS6723	18
FS1956	33	FS6730	11
FS1957	33	FS7010	12
FS1958	33	FS7370	25
FS1960	33	FS7370	25
FS1962	33	FS7386	10
FS1964	33	FS7402	6
FS1966	33	FS7403	6
FS1970	33	FS7403A	6
FS1973	33	FS7403B	6
FS1980	34	FS7404	6
FS1982	34	FS7405	13
FS1983	34	FS7407	13
FS1984	34	FS7410	6
FS1990	34	FS7415	6
FS1992	34	FS7420	26
FS1994	34	FS7426	26
FS1997	34	FS8010	9
FS1998	34	FS8012	9
FS1999	34	FS8050	21
FS2010	11	FS8210	30
FS2014	14	FS8211	18
FS2015	14	FS8215	30
FS2019	15	FS8220	23
FS2020	15	FS8230	31
FS2021	15	FS9650	20
FS2025	15	FSA121	25
FS2520	31	FSA211	24
FS2530	31	FSA23	20
FS2710	15	FSA24	17
FS2712	15	FSA310	18
FS2715	15	FSA319	23
FS2810	24	FSA36	27
FS2814	24	FSA38	7
FS4050	9	FSA49	15
FS4080	9	FSA52	22
FS4086	9	FSA58	8
FS4090	9	FSA58	13
FS4107	9	FSA59	6
FS5010	9	FSB213	29
FS5014	9	FSB218	23
FS5556	20	FSB226	24
FS6405	11	FSB321	26
FS6410	11	FSB36	23
FS6415	11	FSB37	23
FS6505	14	FSB414	23
FS6510	14	FSB53	22
FS6710	22	FSF213	8
FS6712	23	FSF2131	8
FS6720	11	FSF2131	11

Part code	Page
FSF27	13
FSF29	8
FSF82	11
FSF80L	11
FSF80R	11
FSF510	6
FSF54	8
FSF81R	11
FSF81L	11
FSF84	13
FSF86	11
GU3013A	23
GU4090	20
GU4090	30
GU6070	17
GU6070	30
GU6510	30
HYD2250	8
HYD2315A	31
HYD2350	12
HYD2350	31
HYD4710	24
HYD4715	8
HYD4715	9
HYD4724	24
HYD4750	24
HYD4755	24
HYD4780	24
HYD4785	24
HYD5310	24
HYD5318	24
HYD9810	8
MOT9141	9
ST4022	7
ST4025	7
ST9015	20
ST9016	23
ST9021	11
ST90281	23
ST9118	23

Part code	Page
-----------	------

Specifications subject to change.

We reserve the right to make changes to the machine without at the same time these instructions are change.



Producent:
Lindholdt Maskiner A/S
6818 Årre DK.