

PARTS CATALOG



2030/40 ECONOMY

VER: 2.3

INDEX

Symboler

1/2" Bulk..... 26
2 Pin Super seal Female..... 102
2 Pin Super seal Male..... 102
3/4" Bulk..... 26
3/4" Tredo Ring..... 26
3 Pin Super seal Male..... 102
6 Pin Super seal Female..... 102
6 Pin Super seal Male..... 102
12 V. Socket..... 55
20mm Bolt..... 27
20mm Lockings Nut..... 27
20mm Pin..... 18
40 Amp Fuse..... 97

A

A/C Hose thick evaporator..... 64
A/C Hose thin evaporator..... 64
Adapter Plate..... 20
Adapter set 3-sections..... 22
A-Frame Cat 0..... 27
Air filter Element 2030..... 9
Air filter Element 2040..... 9
Airfilter Housing 2030..... 45
Airfilter Housing 2040..... 46
Alu Rail Left Door..... 75
Alu Rail Right Door..... 75
Anchor Plate..... 12
Anchor Plate bolt..... 11
Angle Joint..... 15, 80
Angle Mounting..... 57
Anker Plate Complete Left..... 11
Anker Plate Complete Right..... 11
Attachment for spring mounting..... 11
Axel long..... 80
Axel Short..... 80

B

Ball Bar..... 33
Battery..... 97
Beacon flasher..... 100
Bearing..... 80
Bearing 20mm..... 18
Bearing 25mm Lift Cyl..... 25
Bearing 30mm..... 29
Bearing 35mm..... 29
Bearing Complete 20mm..... 18
Bearing head for Velding Lift Cyl..... 25
Bearing Head Without Bearing..... 29
Bent Cover..... 56
Blink lamp..... 99
Blower..... 53
Blower Switch..... 54
Bolt..... 35, 48, 63, 73, 77, 78
Bolt 5X16 mm..... 53
Bolt anchor plate..... 12
Bolt Bracket Engine..... 30

Bolt Bracket Hydrostat..... 30
Bolt for Bell Housing..... 49
Bolt for Clutch..... 49
Bolt For Lower Joint..... 29
Bolt for Pos. 1..... 19
Bottom plate..... 77
Botton head Bolt..... 61
Botton head Bolt Long..... 61
Bracket..... 56, 63, 83
Bracket for Air filter 2030..... 45
Bracket for airfilter 2040..... 46
Bracket for Relay..... 52
Bracket For Wiring..... 38
Bracket Fuel Tank..... 34
Brackets..... 84
Bracket Steering Cyl..... 18
Brake Cable..... 12
Brake Drum..... 12
Brake Drum L/R..... 11
Brake Spring..... 11
Brake Switch..... 15
Braket for Fuel Tank..... 38
Bulk..... 63
Bulkhead 5/8..... 64
Bulkhead 7/8..... 64
Bulp Panel 4 pcs..... 54
Bulp Panel 8 pcs..... 54
Bushing for Engine Cover..... 37
Bushing for Welding..... 29
Buttom Plate..... 76

C

Cabin Filter..... 67
Cabin Filter 2030/40..... 9
Cabin Locking Bracket 1..... 31
Cabin Locking Bracket 2..... 31
Cabin Wiring..... 92
Cable Bracket L..... 12
Cable Bracket R..... 12
Cable for Maneuver Valve..... 22
Cable Set..... 81, 97
Cable Set for Brakes..... 10
Cable Set for Hand Brake..... 11
Cast Tool..... 102
Cast Tool Set for Multi Connectors (14, 15)..... 102
Ceiling coverings..... 72
Ceiling coverings Plast Roof..... 72
Clamp..... 63, 77
Clamp 2040..... 48
Clotching for Maneuvre Console..... 68
Clotching Rear..... 70
Clotching Steering Console..... 69
Clutch Housing..... 49
Clutch "one pice"..... 49
Coil maneuver valve..... 23
Complete shut-off valve..... 23
Connection 1/2" - 16mm..... 21
Connection 3/4" - 1"..... 21
Connection 3/4" - 3/4"..... 21
Connection Tube..... 43
Connection Tube with Venting..... 43
Connector for SWF Switches..... 102

Connector Generator.....	102
Consol.....	99
Contact w / Lock.....	24
Control box.....	24
Coupling.....	41
Cover.....	52, 54, 81, 97
Coverage For Trolling.....	56
Cover Female Pins.....	104
Cover for a/c.....	76
Cover Left.....	56
Cover Male Pins.....	104
Cover Maneuver Console.....	78
Cover Right.....	56
Cover Steering Console.....	78

D

Distributing Wiring.....	98
Distributor Cables Fibreglas roof.....	89
Door Glass Left.....	59
Door Glass Left Coloured.....	59
Door Handle.....	56
Draw Bar.....	33
Driving Cable.....	10, 15
Driving Cable 1800mm.....	80
Dust Cap Black gr.1 FASTER.....	26
Dust Cap Black gr.1 FOSSWINKEL.....	26
Dust Cap Blue gr.1. FASTER.....	26
Dust Cap Blue gr.1 FOSSWINKEL.....	26
Dust Cap red gr.1 FASTER.....	26
Dust Cap red gr.1 FOSSWINKEL.....	26
Dust Cap red gr.2.....	26

E

Emblem Flash Light.....	52
Engine Bracket.....	30
Engine Bracket for Air filter 2030.....	45
Engine Bracket with A/C.....	30
Engine Cover Bolt.....	39
Engine Cover Finger Bolt Head.....	39
Engine Cover Left Blue Part.....	39
Engine Cover Mid Grey Front.....	39
Engine Cover Mid Grey Front for hose.....	39
Engine Cover Mid Grey Top.....	39
Engine Cover Mountings.....	39
Engine Cover Reflex.....	39
Engine Cover Right Blue Part.....	39
Engine Covers Complete.....	39
Engine Cover Vitra Stickers.....	39
Engine oil Filter 2030.....	9
Engine oil Filter 2040.....	9
Engine Pre Heater Connector.....	50
Engine Wiring 2030.....	96
Engine Wiring 2040.....	96
Evaporator/Radiator.....	64
Expansion Container.....	42

F

Fan push 2030.....	44
Fan push 2040.....	44
Fan suction 2040.....	44
Female Pins.....	104
Filler Cap.....	20

Filter Element 2030.....	45
Filter Element 2040.....	46
Filter element for Filler cab 2030/40.....	9
Filter for Filler Cap.....	20
Finger Bolt.....	67
Flange for Manchet.....	76
Flange for Motor Left Side Front.....	16, 17
Flange for Motor Rear L./R.....	16, 17
Flange for Motor Right Side Front.....	16, 17
Flashing beacon.....	99
Flatface gr.1 1/2" Female.....	26
Flatface gr.1 3/8" Female.....	26
Flatface gr.2 1/2" Female.....	26
Flatface gr.2 1/2" Male.....	26
Flatface gr.2 3/4" Female.....	26
Flatface gr.2 3/4" Male.....	26
Flex 7,4mm.....	13
Flex 13mm.....	13
Flex 19mm.....	13
Flex 25mm.....	13
Flex 28mm.....	13
Flex 90 cm.....	53
Flex tube Kit 2040.....	48
Floor Mat.....	71
Foam.....	63
Forward Attachment Pin for 4mm Lock.....	37
Forward Attachment Pin for 5mm Lock.....	37
Frame.....	52
Front Bracket Hydraulic Tank.....	20
Front Lamp.....	99
Front Lift.....	27
Fuel filler cap.....	34
Fuel Filter 2030/40.....	9
Fuel Gauge.....	34, 38
Fuel Tank.....	34
Fuse.....	52
Fuse Box.....	52
Fuse Bracket.....	97
Fuse Socket.....	97

G

Gasket for 1-Section.....	22
Gasket for Lift Cyl.....	25
Gasket Manifold/Rod 2040.....	48
Gaskets Steering Cyl.....	18
Gas Spring.....	15
Generator 40 Amp.....	50
Generator 60 amp - Kit.....	50
Generator Bracket.....	50
Generator Connector.....	50
Glider / Coil PTO valve.....	19
Grille.....	42
Grille Lock.....	42

H

Hand Brake.....	81
Hand Brake Console.....	81
Hand Brake Lever.....	11
Hand Brake Switch.....	81
Handle.....	64
Handle for Side Window.....	61
Hatch Hydrostat.....	35

Hatch Rear Wheel Left..... 35
 Hatch Rear Wheel Right..... 35
 Hazard switch..... 54
 Headlight Left..... 100
 Headlight Right..... 100
 Heating Handle..... 63
 Heating valve..... 64
 Hexagon Nippel for Wheel Motor..... 16
 Horn..... 51
 Horn Ground Wire..... 51
 Hose..... 63
 Hose 2030..... 45
 Hose 2040..... 46
 Hose clamp..... 43, 44, 64
 Hose clamp 2030..... 45
 Hose clamp 2040..... 46
 Hour meter..... 54
 Hydraulic Tank..... 20
 Hydrostat..... 15
 Hydrostat Bracket..... 15, 30
 Hydrostat Lever..... 15
 Hætte..... 61

I

Ignition Switch..... 55
 Indicator Relay (No Picture)..... 55
 Inner Bracket Left..... 57
 Inner Bracket Right..... 57
 Inner Door Handle Left..... 56
 Inner Door Handle Right..... 56
 Inner Lower Bracket Left..... 57
 Inner Lower Door Bracket Right..... 57
 Inner Upper Door Bracket Right..... 57
 Insulation A/C Housing..... 74
 Insulation Cabin Rear..... 74
 Insulation Cover Plate..... 73
 Insulation Maneuver Console..... 74
 Insulation Maneuver Console 2..... 74
 Insulation Seat Console..... 73
 Insulation Seat Console 2..... 73
 Insulation Seat Console 3..... 73
 Insulation Steering Colum..... 73
 Intake Grill..... 67

J

Joint for Driving Cable..... 10
 Joint for Velding..... 27
 Joystick..... 24

L

Lamp socket..... 24
 Lever..... 22
 Lever Backward..... 80
 Lever Cable..... 10
 Lever Forward..... 80
 Lift Cylinder..... 25
 Lock for Fuel Tank..... 38
 Locking Nut..... 18, 63
 Locking Pin..... 27
 Locking Ring 30 mm for pos. 1..... 29
 Locking Ring 35 mm for pos. 6..... 29
 Locking Ring for Pos 3..... 29

Loud Speaker Set..... 52

M

Main Power Relay..... 55
 Male Pins..... 104
 Manchet for Cabel..... 76
 Manchet for cable..... 77
 Manchet Lift Cyl..... 25
 Maneuver Cover..... 79
 Maneuver Valve Adapter kit..... 22
 Maneuver Valve complete..... 22
 Manifold gasket 2030..... 48
 Manifold gasket 2040..... 48
 Manoeuvring Valve 3 sec..... 23
 Micro-Relay..... 102
 Mirror..... 56, 62
 Mirror Arm..... 56
 Mounting Bracket..... 31
 Mounting set flashing beacon..... 99
 Mud Flap..... 36
 Multi Connector 2 Pin Female..... 104
 Multi Connector 2 Pin Male..... 104
 Multi Connector 3 Pin Female..... 104
 Multi Connector 3 Pin Male..... 104
 Multi Connector 4 Pin Female..... 104
 Multi Connector 4 Pin Male..... 104
 Multi Connector Female 19 + 20 Pin ITT-Canon..... 102
 Multi Connector Female 19 Pin ITT-Canon..... 103
 Multi Connector Male 19+20Pin ITT-Canon..... 103
 Multi Connector Male 19 Pin ITT-Canon..... 103
 Multi Switch Stick..... 55
 Møtrik..... 35, 61

N

Nippel 7/8 18L..... 17
 Nippel 7/16 8L..... 17
 Nipple for Pressure switch..... 64
 Nozzle..... 66
 Nut..... 52, 73, 78

O

Oil Level Meter..... 20
 Oil Termostat..... 41
 Option..... 99
 Orbitrol..... 18
 O-Ring Hydrostat / Pump..... 19
 O-Ring Return Filter 2030..... 20
 O-Ring Return Filter 2040..... 20
 O-Ring Steering pump / Engine..... 19
 Outer Lower Door Hinge..... 57
 Outer Upper Door Hinge..... 57

P

Panel for Joystick..... 24
 Panel - Manevver - Joystick..... 79
 Panel - Manevver - Manual..... 79
 Pedal Housing..... 80
 Pin For All Female UMNL Connectors..... 103
 Pin For All UMNL Male Connectors..... 103
 Pin Front Lift Cyl..... 25
 Pin Lift-A-Frame..... 27

Pin Lift-Chassis..... 27
Pin lift-Cylinder..... 27
Pin Power for ITT-Canon Female Connector..... 103
Pin Power for ITT-Canon Male Connector..... 103
Pin Rear Lift Cyl..... 25
Pin Signal for ITT-Canon Female Connector..... 103
Pin Signal for ITT-Canon Male Connector..... 103
Pins super seal Female..... 102
Pins super seal Male..... 102
Pin steering Cyl..... 18
Pivot Bracket for Fuel Tank..... 38
Pollen Filter (No Picture)..... 67
Pom Fazet Washer..... 57
Pom Washer Facet..... 61
Pom Washer Flat..... 61
Pre Heater Relay (No Picture)..... 55
Pressure control valve..... 23
Pressure Valve..... 22
PTO / Maneuvering Pump 2030..... 19
PTO / Maneuvering Pump 2040..... 19
PTO switch..... 54
PTO valve..... 19
Pulley..... 43
Pulley on Crank shaft..... 43
Pulley on Crankshaft 2040/30..... 44
Pump steering 2030/40..... 19

R

Radiator..... 63, 64
Radiator Angle Hose..... 43
Radiator cap..... 41
Radiator complete Cleanair..... 41
Radiator Hose..... 43, 44, 64
Radio and CD Player..... 52
Radio Panel Fiberglas roof..... 89
Rear attachment Connection Beam..... 37
Rear attachment Left rear Part..... 37
Rear attachment Lower front part..... 37
Rear attachment Right rear Part..... 37
Rear Bracket Hydraulic Tank..... 20
Rear Light Left + Right..... 98, 99
Rear Protection Plate New..... 32
Rear Protection Plate Old..... 32
Rear Window..... 60
Rear Window Coloured..... 60
Relay..... 52
Relay high/low Beam..... 55
Relay Imobillizer..... 55
Relay sockets..... 24
Relay Standard..... 102
Return Block Rear 3/4"-1/4"..... 21
Return Block Rear 3/4"-3/8"..... 21
Return Block Rear 3/8"..... 21
Return Filter 2030..... 20
Return Filter 2040..... 20
Return filter Element 2030..... 9
Return filter Element 2040..... 9
Rim..... 14
Rivets..... 75
Roller - Plast..... 10
Roller - Steel..... 10
Roof Fiberglas..... 86

Roof Plast..... 86
Roset..... 62
Rubber..... 62
Rubber bush..... 77
Rubber Compensators..... 30
Rubber mounting - Cabin front..... 85
Rubber mounting - Cabin rear..... 85
Rubber Sealing..... 63
Rubber Sealing 16mm..... 76
Rubber Sealing 21mm..... 76
Rubber Sealing Large..... 63
Rubber Strip..... 57
Rubber strip 4x10..... 77
Rubber strip 5x14..... 77
Rubber Support For Lock..... 38
Rubber Washer..... 41, 61
Rubber Washer 1..... 56
Rubber Washer 2..... 56

S

Screw..... 52, 66, 77
Screws..... 63
Seat Air Suspended..... 84
Seat Mecanical Suspention..... 84
Shelf with fiberglass roof..... 52
Shelf with plastic roof..... 52
Shut-off valve incl. coil..... 23
Side Window..... 60
Side Window Coloured..... 60
Silencer 2030/2040..... 48
Small Cover Left..... 56
Small Cover Right..... 56
Small PTO valve complete..... 23
Socket for Beacon flasher..... 100
Socket for Micro-relay..... 102
Socket for relay Standard..... 102
Spacer..... 12, 44
Spacer 5 mm..... 30
Spacer 12 mm..... 30
Spool PTO valve 12V..... 19
Starter 2030..... 50
Starter 2040..... 50
Steering console..... 51
Steering Cyl..... 18
Steering Wheel..... 51
Steering Wheel Centre Cover..... 51
Step Left..... 28
Step Right..... 28
Sticker "2030"..... 87
Sticker "2030" Economy..... 87
Sticker "2040" Economy..... 87
Sticker for joystick top..... 24
Sticker for panel..... 24
Sticker - Joystick..... 79
Sticker - Panel..... 79
Sticker "Vitra"..... 87
Strips..... 52
Suction Hose 1"..... 21
Suction Hose 3/4"..... 21
Suction Hose 16mm..... 21
Suction Hose Clamp 1"..... 21
Suction Hose Clamp 1/2"..... 21

Supportpart for engine cover..... 37
 Switch Aux. / Trailer..... 54
 Switches..... 52
 Switch for Seat Heating..... 81
 Symbol Blower..... 54
 Symbol Hazard..... 54
 Symbol PTO..... 54
 Symbol Viper..... 54

T

Taillight..... 100
 Taper..... 63, 64
 The bypass valve complete..... 23
 Threaded Bracket..... 56
 Threaded Rod..... 78
 Throttle cable..... 83
 Tire 23*10,50-12..... 14
 Top Link..... 27
 Trailer Connector..... 98
 Trolling..... 56

U

UMNL Connector 4 Pin Male..... 103
 UMNL Connector 6 Pin Female..... 103
 UMNL Connector 6 Pin Male..... 103
 UMNL Connector 9 Pin Female..... 103
 UMNL Connector 9 Pin Male..... 103
 UMNL Connector 12 Pin female..... 103
 UMNL Connector 12 Pin Male..... 103
 Unbraco Bolt..... 42
 Unbraco Bolt for pos. 2..... 19
 Unbraco Bolt Mud Flap..... 36
 Upper Bearing Pin..... 29
 Upper Connection..... 29

V


Valve..... 63
 Valve incl. coil..... 23
 Valv incl. coil..... 23
 V-Belt..... 44
 V-Belt 2030/40..... 9
 V-Belt - A/C..... 44
 V-Belt A/C 2030/40..... 9
 Vent Cap Lift Cyl..... 25
 Ventilation Fan push..... 43
 Ventilation Fan suction..... 43
 Ventil incl. spole..... 23
 Venting Nut..... 43
 Viper Switch..... 54

W

Warning Triangle..... 87
 Washer..... 36, 41, 52, 56, 61, 63, 73, 77
 Washer 20mm..... 27
 Washer Large..... 73
 Wheel..... 14
 Wheel bolts..... 12
 Wheel Motor L..... 16, 17
 Wheel Motor R..... 16
 Wheel Nut..... 11, 14
 Wind Screen Buttom..... 58

Wind Screen Buttom Coloured..... 58
 Wind Screen Top..... 58
 Wind Screen Top Coloured..... 58
 Wiper arm..... 62
 Wiper blade..... 62
 Wiper Complete set..... 62
 Wiper Motor..... 62
 Wiring..... 52, 53
 Wiring Chassis..... 101
 Wiring Chassis to Roof..... 93, 94
 Wiring Headlight roof back..... 91
 Wiring Headlight roof front..... 91
 Wiring Left Rear Light..... 98
 Wiring PTO-valve..... 95
 Wiring Radio Panel..... 90
 Wiring Right Rear Light..... 98
 Wiring Seat..... 88
 Wiring Trailer Connector..... 98
 Working light Fiberglas roof..... 89
 Working light Front..... 100
 Working light Rear..... 100
 Work Lamp..... 99


FIG. 1 FILTERS/FAN BELT



KEY	PART CODE	DESCRIPTION	DIV.
1	MOT9105	Air filter Element 2030	*
1a	MOT9103	Air filter Element 2040	
2	HYD1916	Return filter Element 2030	
2a	HYD1927	Return filter Element 2040	
3	HYD1912	Filter element for Filler cab 2030/40	
4	MOTC1520	Engine oil Filter 2030	*
4a	MOTC1525	Engine oil Filter 2040	
5	MOTC1530	Fuel Filter 2030/40	
6	DIV2072	Cabin Filter 2030/40	
7	MOTC2015	V-Belt 2030/40	
8	MOTC2020	V-Belt A/C 2030/40	


* 2030 with Cat 1.6 from...50 to...186
Use airfilter and oilfilter from 2040

FIG. 2 CABLES



KEY	PART CODE	DESCRIPTION	DIV.
1	DIV4135	Cable Set for Brakes	
2	DIV4116	Lever Cable	
3	DIV4121	Driving Cable	
4	DIV4125	Joint for Driving Cable	
5	DIV4131	Roller - Plast	Not illu
5a	DIV4133	Roller - Steel	Not illu


FIG. 3 BRAKES



KEY	PART CODE	DESCRIPTION	DIV.
1	See page 12	Anker Plate Complete Right	
2	See page 12	Anker Plate Complete Left	
3	See page 12	Brake Drum L/R	
4	HJ5010	Wheel Nut	
5	BM2340	Anchor Plate bolt	
6	ST3415	Hand Brake Lever	
7	ST3420	Attachment for spring mounting	
8	ST9003	Brake Spring	
9	DIV4135	Cable Set for Hand Brake	

Up until ...113

FIG. 4 BRAKES



KEY	PART CODE	DESCRIPTION	DIV.
1	BR1020	Brake Drum	
2	BR1015	Anchor Plate	
3	ST3146	Cable Bracket R	
4	ST3145	Cable Bracket L	
5	ST3147	Spacer	
6	BM5260	Unbraco bolt	
6a	BM2041	Nut	
7	HJ5145	Wheel bolts	
8	DIV4138	Brake Cable	
9	BM2445	Bolt anchor plate	Not illu


Anchor Plates and brake drums on page 11 are deleted.

Replaced of a complete brake kit that consists a completely new brake system. (See picture)

To 2030 used the kit BR2030.


To 2037 used the kit BR2040.

FIG. 5 PROTECTIVE FLEX




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV6030	Flex 28mm	1 Meter
2	DIV6020	Flex 25mm	1 Meter
3	DIV6018	Flex 19mm	1 Meter
4	DIV6014	Flex 13mm	1 Meter
5	DIV6010	Flex 7,4mm	1 Meter

FIG. 6 Wheel



KEY	PART CODE	DESCRIPTION	DIV.
1	HJ1020	Wheel	
2	HJ1040	Tire 23*10,50-12	
3	HJ5010	Wheel Nut	
4	HJ2010	Rim	


FIG. 7 HST/HST CONTROLS



KEY	PART CODE	DESCRIPTION	DIV.
1	DIV4327	Gas Spring	
2	DIV4121	Driving Cable	
3	DIV4125	Angle Joint	
4	ST2512	Hydrostat Lever	
5	ST2513	Hydrostat Bracket	
6	EL4050	Brake Switch	
7	HYD1705	Hydrostat	
8	ST2515	Spring Bracket	

Tryk ventiler

FIG. 8 WHEEL MOTORS 2030




KEY	PART CODE	DESCRIPTION	DIV.
1	HYD1715	Wheel Motor L	
2	HYD1717	Wheel Motor R	
3	ST9445	Flange for Motor Left Side Front	**
4	ST9440	Flange for Motor Right Side Front	**
4	ST9450	Flange for Motor Rear L./R	*
5	HYD4735	Nippel for Wheel Motor	

* From...114 Also for front motors

** Up until...113

FIG. 9 WHEEL MOTORS 2040




KEY	PART CODE	DESCRIPTION	DIV.
1	ST9455	Flange for Motor Left Side Front	**
2	ST9460	Flange for Motor Right Side Front	**
3	ST9465	Flange for Motor Rear L./R	*
4	HYD1760	Wheel Motor	
5	HYD4745	Nippel 7/8 18L	
6	HYD4746	Nippel 7/16 8L	
7	BM5255	Bolt	

* From...114 Also for front motors


** Up until...113

FIG. 10 STEERING COMPONENTS




KEY	PART CODE	DESCRIPTION	DIV.
1	HYD2308	Steering Cyl.	
1A	HYD2325	Gaskets Steering Cyl.	
2	HYD2315A	Bearing Complete 20mm	
3	HYD2315	Bearing 20mm	
4	HYD1551	Orbitrol	
5	ST3042	Bracket Steering Cyl.	
6	ST3310	Pin steering Cyl.	
7	ST3320	20mm Pin	
8	ST1078	Locking Nut	

FIG. 11 PTO




KEY	PART CODE	DESCRIPTION	DIV.
1	HYD1558	Pump steering 2030/40	
2	HYD1563	PTO / Maneuvering Pump 2030	
2a	HYD1564	PTO / Maneuvering Pump 2040	
3	HYD1804	PTO valve	
4	HYD1807	Spool PTO valve 12V	
5	HYD1806	Glider / Coil PTO valve	
6	HYP2020	O-Ring Hydrostat / Pump	
7	HYP2030	O-Ring Steering pump / Engine	
8	BM1570	Bolt for Pos. 1	
9	BM5490	Unbraco Bolt for pos. 2	

FIG. 12 HYDRAULIC RETURN SYSTEM




KEY	PART CODE	DESCRIPTION	DIV.
1	STL6787	Hydraulic Tank	
2	HYD1912	Filter for Filler Cap	
3	HYD1910	Filler Cap	
4	HYD1917	O-Ring Return Filter 2030	
4a	GU4624	O-Ring Return Filter 2040	
5	ST7015	Adapter Plate	
6	HYD1950	Oil Level Meter	
7	ST3031AA	Rear Bracket Hydraulic Tank	
8	ST3030	Front Bracket Hydraulic Tank	
9	HYD1915	Return Filter 2030	
9a	HYD1925	Return Filter 2040	

FIG. 13 HYDRAULIC RETURN SYSTEM




KEY	PART CODE	DESCRIPTION	DIV.
1	HYD7069	Suction Hose 16mm	1 Meter
2	HYD7070	Suction Hose 3/4"	1 Meter
3	HYD7120	Suction Hose 1"	1 Meter
4	FI1350	Connection 1/2" - 16mm	
5	FI1418	Connection 3/4" - 3/4"	
6	FI1410	Connection 3/4" - 1"	
7	BM9215	Suction Hose Clamp 1/2"	
8	BM9220	Suction Hose Clamp 1"	
9	ST3412	Return Block Rear 3/4"-1/4"	
9a	ST3413	Return Block Rear 3/8"	
9b	ST3414	Return Block Rear 3/4"-3/8"	
10	ST3410	Used no more.	

FIG. 14 MANEUVER / FRONT LIFT



KEY	PART CODE	DESCRIPTION	DIV.
1	HYD3115	Maneuver Valve complete	
2	HYD3107	Adapter set 3-sections	
3	HYD3109	Lever	
4	HYD3108	Maneuver Valve Adapter kit	
5	HYD3124	Pressure Valve	
6	HYD3114	Cable for Maneuver Valve	
7	HYD3122	Gasket for 1-Section	

FIG. 15 JOYSTICK



KEY	PART CODE	DESCRIPTION	DIV.
1	HYD3180	Valve incl. coil	*
1a	HYD3181	Valv incl. coil	**
2	HYD3170	Small PTO valve complete	*
2a	HYD3178	Pressure control valve	
2b	HYD3171	Small PTO valve complete	**
3	HYD3165	Shut-off valve incl. coil	
4	HYD3166	Block	
5	HYD3165	Complete shut-off valve	
6	HYD3124	Pressure control valve	
7	HYD3135	Coil maneuver valve	
8	HYD3130	Manoeuvring Valve 3 sec.	

* Up until...182


** From...183

FIG. 16 JOYSTICK




KEY	PART CODE	DESCRIPTION	DIV.
1	EL2250	Joystick	
2	EL2254	Control box	
3	EL90181A	Relay sockets	
4	EL1120	Lamp socket	
4A	EL1105	Contact w / Lock	
5	EL1170	Panel	
6	DIV5110	Sticker for panel	
6A	DIV5112	Sticker for joystick top	
7	LS9503	Panel for Joystick	

FIG. 17 FRONT LIFT



KEY	PART CODE	DESCRIPTION	DIV.
1	HYD2322	Lift Cylinder	
2	HYD2317A	Bearing head for Velding Lift Cyl.	
3	HYD2317B	Bearing 25mm Lift Cyl.	
3a	HYD2317	Bearing head for Velding Lift Cyl.	
4	ST4210	Pin Front Lift Cyl.	
5	GU5110	Manchet Lift Cyl.	
6	HYD2330	Vent Cap Lift Cyl.	
7	ST4265	Pin Rear Lift Cyl.	
8	HYD2325	Gasket for Lift Cyl.	


FIG. 18 QUICK COUPLERS



KEY	PART CODE	DESCRIPTION	DIV
1	HYD4001	Flatface gr.2 3/4" Female	
2	HYD4010	Flatface gr.2 1/2" Female	
3	HYD5060	3/4" Bulk	
4	HYD5320	3/4" Tredo Ring	
5	HYD4019	Flatface gr.1 1/2" Female	
6	HYD4018	Flatface gr.1 3/8" Female	
7	HYD5058	1/2" Bulk	
8	HYD5318	1/2" Tredo Ring	
9	HYD4004	Flatface gr.2 3/4" Male	
10	HYD4014	Flatface gr.2 1/2" Male	
11	HYD5054	3/8" Bulk	
12	HYD5314	3/8" Tredo Ring	
13	GU4570	Dust Cap red gr.2	
14	GU4564	Dust Cap red gr.1 FOSSWINKEL	++
15	GU4560	Dust Cap Black gr.1 FOSSWINKEL	++
16	GU4562	Dust Cap Blue gr.1 FOSSWINKEL	++
14A	GU4559	Dust Cap red gr.1 FASTER	--
15A	GU4560	Dust Cap Black gr.1 FASTER	--
16A	GU4557	Dust Cap Blue gr1. FASTER	--


++ Use up to chassis number 384
 -- Use from chassis number 385

FIG. 19 A-FRAME




KEY	PART CODE	DESCRIPTION	DIV.
1	ST4020	A-Frame Cat 0.	
2	STL1051A	Front Lift	
3	ST4100	Pin lift-Cylinder	
4	ST4150	Pin Lift-A-Frame	
5	ST3810	Top Link	
6	BM2650	Washer 20mm	
7	BM2070	20mm Lockings Nut	
8	BM1870	20mm Bolt	
9	KI4015	Locking Pin	
10	ST4100	Pin Lift-Chassis	
11	ST1510	Joint for Velding	

FIG. 20 STEPS




KEY	PART CODE	DESCRIPTION	DIV.
1	ST3059	Step Left	
2	ST3060	Step Right	

FIG. 21 CENTRE LINKAGE



KEY	PART CODE	DESCRIPTION	DIV.
1	ST3026A	Upper Connection	
2	ST1112	Bearing Head Without Bearing	
3	ST3348	Upper Bearing Pin	
4	ST1125	Locking Ring for Pos 3	
5	BM6030	Bolt For Lower Joint	
6	ST1116	Bearing Head Without Bearing	
7	ST1117	Bearing 35mm	
8	ST3335	Bushing for Welding	
9	ST1111	Bearing 30mm	
10	ST1130	Locking Ring 30 mm for pos. 1	
10a	ST1135	Locking Ring 35 mm for pos. 6	

FIG. 22 ENGINE MOUNTINGS




KEY	PART CODE	DESCRIPTION	DIV.
1	ST3041A	Engine Bracket	
1a	ST3041B	Engine Bracket with A/C	
2	ST3049A	Hydrostat Bracket	
3	GU3013	Rubber Compensators	*
3a	GU5024	Rubber Compensators	**
4	BM2350	Bolt Bracket Hydrostat	
5	BM1788	Bolt Bracket Engine	
6	ST304005	Spacer 5 mm. for pos. 3 + 3a	
7	ST304012	Spacer 12 mm. for pos. 3 + 3a	

* Up until...189


** From...190

FIG. 23 CHASSIS PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	ST3034	Cabin Locking Bracket 1	
2	ST3036	Cabin Locking Bracket 2	
3	ST3037	Mounting Bracket	

FIG. 24 CHASSIS PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	ST3025	Rear Protection Plate Old	Is deleted
2	ST3024	Rear Protection Plate New	

FIG. 25 DRAW BAR




KEY	PART CODE	DESCRIPTION	DIV.
1	ST3070	Draw Bar	
2	ST9140	Ball Bar	

FIG. 26 DIESEL TANK




KEY	PART CODE	DESCRIPTION	DIV.
1	STL6758	Fuel Tank	
2	ST3032A	Bracket Fuel Tank	
3	EL2517	Fuel Gauge	
4	ST7028	Fuel filler cap	

FIG. 27 HATCHES




KEY	PART CODE	DESCRIPTION	DIV.
1	ST3023	Hatch Rear Wheel Right	
2	BM1110	Bolt	
3	ST3018	Hatch Hydrostat	
4	BM1118	Bolt	
5	BM2020	Møtrik	
6	ST3018	Hatch Hydrostat	
7	ST3022	Hatch Rear Wheel Left	

FIG. 28 MUD FLAPS




KEY	PART CODE	DESCRIPTION	DIV.
1	GU4010	Mud Flap	
2	BM5420	Unbraco Bolt Mud Flap	
3	BM2805	Washer	

FIG. 29 REAR ATTACHMENT POINTS




KEY	PART CODE	DESCRIPTION	DIV.
1	ST3122	Rear attachment Lower front part	
2	ST3111	Rear attachment Right rear Part	
2a	ST3107	Rear attachment Left rear Part	
3	ST3124	Supportpart for engine cover	
4	GU6640	Bushing for Engine Cover	
5	FS6710	Forward Atachment Pin for 5mm Lock	
5a	FS6712	Forward Atachment Pin for 4mm Lock	
6	ST3114	Rear attachment Connection Beam	
7	ST3123	Front attachment	

FIG. 30 BRACKETS AND LEVERS



KEY	PART CODE	DESCRIPTION	DIV.
1	EL2517	Fuel Gauge	
2	ST3031B	Braket for Fuel Tank	
3	ST7018	Lock for Fuel Tank	
4	GU3013A	Rubber Support For Lock	
5	ST2550	Bracket For Wiring	
6	ST3032A	Pivot Bracket for Fuel Tank	

FIG. 31 ENGINE COVERS




KEY	PART CODE	DESCRIPTION	DIV.
1	GF1210	Engine Covers Complete	
2	GF1212	Engine Cover Left Blue Part	
3	GF1213	Engine Cover Right Blue Part	
4a	GF1216	Engine Cover Mid Grey Top	
4b	GF1217	Engine Cover Mid Grey Front	
4c	GF1217A	Engine Cover Mid Grey Front for hose	Not illu
5	DIV8030	Engine Cover Mountings	
6	DIV5050	Engine Cover Vitra Stickers	
7	DIV2128	Engine Cover Finger Bolt Head	
8	BM5520	Engine Cover Bolt	
9	EL2016A	Engine Cover Reflex	




DIV8033
NEW TYPE BRACKET
USE OF FRAME NO. 138

FIG. 32 COOLING SYSTEM 2030



KEY	PART CODE	DESCRIPTION	DIV.
Radiator has been replaced with KØ1006. Should it be replaced You need 1. KØ1035 kit.			

FIG. 33 COOLING SYSTEM 2030/2040




KEY	PART CODE	DESCRIPTION	DIV.
1	KØ1062	Radiator complete Cleanair	
2	GU1040	Rubber Washer	
3	BM2805	Washer	
4	HYD4947	Coupling	
5	HYD4914	Coupling	
6	HYD4912	Coupling	
7	KØ2020	Radiator cap	
8	KØ9010	Oil Termostat - 2040	
8a	HYD8830	Oil Termostat - 2030	

Pos 1.

Used in Economy models from machine No 61


Except 65-66-67-68.

FIG. 34 COOLING SYSTEM




KEY	PART CODE	DESCRIPTION	DIV.
1	ST30651	Grille	
2	ST2555	Grille Lock	
3	BM5390	Unbraco Bolt	
4	ST2510	for Expansion Container	
5	KØ1210	Expansion Container	

FIG. 35 COOLING SYSTEM 2030



KEY	PART CODE	DESCRIPTION	DIV.
1	MOTC6010	Ventilation Fan push	
1a	MOTC6013	Ventilation Fan suction	
2	MOTC6015	Pulley	
3	GU2114	Radiator Hose	
4	GU2114	Radiator Hose	
5	KØ4120	Venting Nut	
6	MOT1089	Connection Tube with Venting	
7	BM9220	Hose clamp	
8	MOT1069A	Connection Tube	
9	MOT1060	Radiator Angle Hose	
10	MOTC6025	Pulley on Crank shaft	

FIG. 36 COOLING SYSTEM 2040/2030



KEY	PART CODE	DESCRIPTION	DIV.
1	MOTC6014	Fan push 2030	
2	MOTC6014	Fan push 2040	
2a	MOTC6011	Fan suction 2040	
3	GU2140	Radiator Hose	
4	BM9220	Hose clamp	
5	MOTC6030	Pulley on Crankshaft 2040/30	
6	MOTC2015	V-Belt	
6a	MOTC2020	V-Belt - A/C	
7	MOTC6008	Spacer	

FIG. 37 INTAKE PARTS 2030



KEY	PART CODE	DESCRIPTION	DIV.
1	MOT9107	Airfilter Housing 2030	*
2	MOT9105	Filter Element 2030	*
3	MOT2047	Hose 2030	1 mtr.
4	BM9230	Hose clamp 2030	
6	MOT9106A	Bracket for Air filter 2030	
7	ST2541	Engine Bracket for Air filter 2030	


* 2030 with cat 1.6 from 50 to ..187
 use airfilter from 2040
Next page pos. 1-2-3

FIG. 38 INTAKE PARTS 2040




KEY	PART CODE	DESCRIPTION	DIV.
1	MOT9102	Airfilter Housing 2040	
2	MOT9104	Bracket for airfilter 2040	
3	MOT9103	Filter Element 2040	
4	MOTC4970	Intake Hose 2040	
5	BM9230	Hose clamp 2040	
6	ST2540	Bracket for Air filter	

FIG. 39 EXHAUST PARTS 2030




KEY	PART CODE	DESCRIPTION	DIV.
1	MOTC5012	Silencer 2030	
2	MOTC5013	Outlet 2030	
3	MOTC5020	Rod 2030	
4	MOTC5015	Gasket Manifold / Rod 2030	
5	MOTC5017	Manifold Gasket 2030	
6	MOT8300	Flex Tube With Heat protection 2030	

FIG. 40 EXHAUST PARTS 2030/2040




KEY	PART CODE	DESCRIPTION	DIV.
1	MOTC5014	Silencer 2030/2040	
2	MOTC5015	Gasket Manifold/Rod 2040	
3	BM9260	Clamp 2040	
4	BM1334	Bolt	
5	MOT8300	Flex tube Kit 2040	
6	MOTC5017	Manifold gasket 2030	
7	MOTC5018	Manifold gasket 2040	
8	ST9033	Spring	
9	BM5655	Pas bolt	

FIG. 41 CLUTCH PARTS 2030/2040




KEY	PART CODE	DESCRIPTION	DIV.
1	MOT9000	Clutch Housing	
2	MOT9001	Clutch "one pice"	
3	BM2340	Bolt for Clutch	
4	BM5120	Bolt for Clutch Housing	

FIG. 42 GENERATOR / STARTER / HEATER




KEY	PART CODE	DESCRIPTION	DIV.
1	MOTC2010	Generator 40 Amp	
2	EL8190	Generator Connector	
3	MOTC2012	Generator Bracket for pos. 1	
4	MOTC4950	Starter 2030	
4a	MOTC4955	Starter 2040	
5	AC2510	Compressor - A/C	
6	AC2511	Clutch - A/C	
7	STL1288	Generator 60 amp - Kit	
8	MOT1019	Generator Connector for pos. 7	
9	MOTC2013	Bracket for pos. 1 + 7	
10	MOTC2015	V-Belt - Cat 1.1 - 1.6	
11	MOTC2020	V-Belt - Compressor	
12	ST2577	V-Belt Tensioner - Compressor	
13	AC2515	Hose Bracket	
14	AC8046	Hose to capacitor	
15	AC8047	Hose to Evaporator	

FIG. 43 STEERING CONSOLE / HORN




KEY	PART CODE	DESCRIPTION	DIV.
1	RAT1025	Steering console	
2	RAT3005	Steering Wheel	
3	RAT3006	Steering Wheel Centre Cover	
4	EL2520	Horn	
5	EL9152	Horn Ground Wire	

FIG. 44 ROOF PANEL



KEY	PART CODE	DESCRIPTION	DIV.
1	ST3245	Shelf with fiberglass roof	
1a	ST3245A	Shelf with plastic roof	
2	EL1010	Loud Speaker Set	
3	EL1115	Switches	
4	EL1157	Emblem Flash Light	
5	EL1170	Frame	
6	EL4010	Relay	
7	DIV3070	Bracket for Relay	
8	DIV3058	Strips	
9	EL8510	Fuse	
10	EL1031	Fuse Box	
11	BM3002	Screw	
12	BM2515	Washer	
13	BM2001	Nut	
14	EL1185	Cover	
15	EL1018	Radio and CD Player	
16	EL1010	Loud Speaker Set	
17	EL9200	Wiring	

FIG. 45 BLOWER




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV1525	Blower	
2	BM3015	Bolt 5X16 mm	
3	DIV6014	Flex 90 cm	
4	EL9125	Wiring	

FIG. 46 DASH BOARD




KEY	PART CODE	DESCRIPTION	DIV.
1	RAT3015	Bulp Panel 4 pcs	
2	RAT3017	Bulp Panel 8 pcs	
3	RAT3070	Cover	
4	RAT3050	PTO switch	
5	RAT3052	Hazard switch	
6	RAT3060	Switch Aux. / Trailer	
7	RAT3056	Blower Switch	
8	RAT3058	Viper Switch	
9			
10	RAT3064	Symbol PTO	
11	RAT3065	Symbol Hazard	
12			
13	RAT3066	Symbol Blower	
14	RAT3067	Symbol Viper	
15	RAT3022	Operation hours counter.	

FIG. 47 ELECTRONIC PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	RAT3010	Multi Switch Stick	
2	RAT3042	Relay high/low Beam	
3	RAT3042	Relay high/low Beam	
4	RAT3040	Relay Imobillizer	
5	EL4014	Main Power Relay	
6	EL2540	12 V. Socket	
7	RAT3020	Ignition Switch	
8	RAT3044	Pre Heater Relay (No Picture)	
9	RAT3046	Indicator Relay (No Picture)	

FIG. 48 DOOR PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV2312	Inner Door Handle Right	
1A	DIV2310	Inner Door Handle Left	
2	DIV2332	Cover Right	
2A	DIV2330	Cover Left	
3	DIV2342	Small Cover Right	
3A	DIV2340	Small Cover Left	
4	DIV2345	Bent Cover	
5	GL2025	Washer	
6	DIV2320	Door Handle	
7	DIV2350	Rubber Washer 1	
8	DIV2360	Rubber Washer 2	
9	DIV2380	Trolling	
10	DIV8010	Mirror Arm	
11	ST3098	Bracket	
12	DIV8021	Mirror	
9A	DIV2390	Coverage For Trolling	
9B	DIV2385	Threaded Bracket	
9C	DIV2385	Washer	

FIG. 49 DOOR PARTS





KEY	PART CODE	DESCRIPTION	DIV.
1	ST3211	Inner Bracket Left	
1A	ST3215	Inner Bracket Right	
2	DIV2335	Angle Mounting	
3	ST3222	Inner Upper Door Bracket Right	
4	ST3227	Inner Lower Door Bracket Right	
5	ST3238	Outer Upper Door Hinge	
6	GL2020	Pom Fazet Washer	
7	ST3230	Outer Lower Door Hinge	
8	ST3219	Inner Lower Bracket Left	
9	GU6012	Rubber Strip	

FIG. 50 WIND SCREEN




KEY	PART CODE	DESCRIPTION	DIV.
1	GL1010	Wind Screen Top	
2	GL1014	Wind Screen Buttom	
1	GL1510	Wind Screen Top Coloured	
2	GL1514	Wind Screen Buttom Coloured	

FIG. 51 DOOR GLAS




KEY	PART CODE	DESCRIPTION	DIV.
1	GL1524	Door Glass Right Coloured	
2	GL1518	Door Glass Left Coloured	

FIG. 52 SIDE / REAR WINDOWS / SIDE WINDOW LOOK




KEY	PART CODE	DESCRIPTION	DIV.
1	GL1035	Rear Window	
1 A	GL1535	Rear Window Coloured	
2	GL1028	Side Window	
2 A	GL1528	Side Window Coloured	

FIG. 53 SIDE / REAR WINDOWS / SIDE WINDOW LOOK




KEY	PART CODE	DESCRIPTION	DIV.
1	GL8010	Handle for Side Window	
2	GL2020	Pom Washer Facet	
3	BM5425	Botton head Bolt	
3	BM2415	Botton head Bolt Long	
4	BM2620	Washer	
5	BM2021	Møtrik	
6	GL2010	Pom Washer Flat	
7	GU1040	Rubber Washer	
8	GU1210	Hætte	

FIG. 54 SIDE / WIPER




KEY	PART CODE	DESCRIPTION	DIV.
1	VI2020	Wiper Motor	
2	VI2030	Roset	
3	VI2097	Rubber	
4	VI2010	Wiper arm	
5	VI2100	Wiper blade	
6	DIV8021	Mirror	
7	VI4010	Wiper Complete set	

FIG. 55 CABIN HEATING PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	LS9839	Bulk	
2	DIV2012	Radiator	
3	GU1027	Rubber Sealing	
4	GU1026	Rubber Sealing Large	
5	GU2110	Hose	1 meter
6	BM9210	Clamp	
7	DIV2036	Heating Handle	
8	HYD5102	Taper	
9	BM3505	Screws	
10	BM2011	Locking Nut	
11	BM1118	Bolt	
12	BM2615	Washer	
13	DIV2035	Valve	
14	GU6070	Foam	
15	GU6072	Rubber Sealing	
16	LSRF20603	Bracket	

FIG. 56 CABIN HEATING/A/C PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	DIV2009	Radiator	
2	AC2526	Evaporator/Radiator	
3	GU2110	Radiator Hose	1 Meter
4	BM9210	Hose clamp	
5	DIV2036	Handle	
6	DIV2035	Heating valve	
7	HYD5102	Taper	
8	AC8040	A/C Hose thin evaporator	
9	AC8041	A/C Hose thick evaporator	
10	AC5022	Bulkhead 5/8	
11	AC5020	Bulkhead 7/8	
	AC2537	Nipple for Pressure switch	


FIG. 57 CABIN HEATING/A/C PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	AC3020	Fan	
2	AC2542	A / C House	
3	GU6070	Edging strip	
4	GU5020	Vibration damper	
5	GU6027	Rubber List	
6	AC2541	Condensor	


	AC8042	Hose capacitor - pressure filter	- - - Not illu - - -
	AC8043	Hose evaporator - pressure filter	
	AC8046	Hose capacitor - compressor	
	AC8047	Hose compressor - evaporator	
	AC2531	Pressure contact	
	AC2538	Pressure sensor	
	AC2530	Pressure filter	
	AC2532	Bracket pressure filter	

FIG. 58 CABIN VENTILATION PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	DIV2040	Nozzle	
2	BM3530	Screw	
3	DIV1550	Nozzle	

FIG. 59 CABIN VENTILATION PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	DIV2050	Intake Grill	
2	DIV2072	Cabin Filter	
3	DIV2130	Finger Bolt	
4	DIV2070	Pollen Filter (No Picture)	Option

FIG. 60 CLOTHING



KEY	PART CODE	DESCRIPTION	DIV.
1	DIV10504	Clotching for Manoeuvre Console	

FIG. 61 CLOTCHING




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV10502	Clotching Steering Console	

FIG. 62 CLOTCHING




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV10503	Clenching Rear	

FIG. 63 FLOOR MAT




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV1052A	Floor Mat	

FIG. 64 INDER ROOF




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV1051	Ceiling coverings Fiberglas Roof	
2	DIV1051A	Ceiling coverings Plast Roof	

FIG. 65 INSULATION PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV1025	Insulation Steering Colum	
2	DIV1027	Insulation Seat Console	
3	LS9813	Insulation Cover Plate	
4	BM2020	Nut	
5	ST3510	Bolt	
6	BM2620	Washer	
7	BM2531	Washer Large	
8	DIV1042	Insulation Seat Console 2	
9	DIV1030	Insulation Seat Console 3	

FIG. 66 INSULATION PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV1036	Insulation Maneuver Console	
2	DIV1034	Insulation Maneuver Console 2	
3	DIV1040	Insulation Cabin Rear	
4	DIV1044	Insulation A/C Housing	
5	DIV1038	Insulation Maneuver Console	

FIG. 67 CABIN PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV1054	Alu Rail Left Door	
2	DIV1055	Alu Rail Right Door	
3	ST9135	Rivets	

FIG. 68 CABIN PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	ST3095	Buttom Plate	
2	ST30914	Flange for Manchet	
3	GU5150	Manchet for Cabel	
4	GU1027	Rubber Sealing 16mm	
5	GU1026	Rubber Sealing 21mm	
6	ST2710	Cover for a/c	

FIG. 69 CABIN PARTS




KEY	PART CODE	DESCRIPTION	
1	ST3095A	Bottom plate	
2	ST30914	Flange for Manchet	
3	GU5150	Manchet for cable	
4	GU1116	Clamp	
5	GU1012	Rubber bush	
6	GU1026	Rubber bush	
7	GU6072	Rubber strip 4x10	
8	GU6070	Rubber strip 5x14	
9	BM1118	Bolt	
10	BM2795	Washer	
11	BM3505	Screw	

FIG. 70 CABIN COVERS




KEY	PART CODE	DESCRIPTION	DIV.
1	BM3110	Bolt	
2	BM3015	Bolt	
3	BM8210	Threaded Rod	
4	BM2020	Nut	
5	LS9804	Cover Maneuver Console	
6	LS9808	Cover Steering Console	

FIG. 71 MANEUVER COVERS




KEY	PART CODE	DESCRIPTION	DIV.
1	LS9507	Panel - Manevver - Manual	
2	LS9503	Panel - Manevver - Joystick	
3	DIV5110	Sticker - Panel	
4	DIV5112	Sticker - Joystick	

FIG. 72 CONTROL PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	ST3096	Pedal Housing	
2	ST1086	Axel long	
3	ST1087	Axel Short	
4	ST9020	Bearing	
5	LS12115	Lever Forward	
6	LS12112	Lever Backward	
7	ST9022	Bearing	
8	BM9010	Angle Joint	
9	DIV4121	Driving Cable 1800mm	

FIG. 73 BRAKING PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	ST2780	Hand Brake Console	
2	DIV4105	Hand Brake	
3	EL1230	Switch for Seat Heating	
4	EL4100	Hand Brake Switch	
5	GU1009	Cover	
6	DIV4135	Cable Set	

FIG. 73A BRAKING PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			

FIG. 74 THROTTLE PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV4116	Throttle cable	
2	ST3051A	Bracket	
3	DIV4109	Gas lever	

FIG. 75 SEAT




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV1080	Seat Mecanical Suspension	
2	ST30911	Brackets	
3	DIV1085	Seat Air Suspended	Option

FIG. 76 CABIN SUSPENSIONS




KEY	PART CODE	DESCRIPTION	DIV
1	GU3016	Rubber mounting - Cabin front	
2	BM1838	Bolt	
3	BM2635	Washer	
4	BM2051	Locking not	
5	GU3008	Rubber mounting - Cabin rear	

FIG. 77 ROOF




KEY	PART CODE	DESCRIPTION	DIV.
1	GF2020	Roof Fiberglas	
2	GF2025	Roof Plast	

FIG. 78 DECOR PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	DIV5010	Warning Triangle	
2	DIV5050	Sticker "Vitra"	
3	DIV5035	Sticker "2030"	
4	DIV5036	Sticker "2030" Economy	
5	DIV5037	Sticker "2040" Economy	

FIG. 79 SEAT WIRING



KEY	PART CODE	DESCRIPTION	DIV.
1	EL9005	Wiring Seat	


FIG. 80 RADIO PANEL



KEY	PART CODE	DESCRIPTION	DIV.
1	EL9112	Working light Fiberglas roof	
2	EL9116	Distributor Cables Fiberglas roof	
3	EL9115	Radio Panel - Roof	*

* t.o.m. 0.196


FIG. 80A WIRING RADIO PANEL 2045/60



KEY	PART CODE	DESCRIPTION	DIV
1	EL9108	Wiring Radio Panel	*

* f.o.m. 197

FIG. 81 WIRING ROOF



KEY	PART CODE	DESCRIPTION	DIV
1	EL9113	Wiring Headlight roof front	*
2	EL9114	Wiring Headlight roof back	
3	HYD4780	Clamp	


* f.o.m. 0.78

FIG. 82 CABINE WIRING




KEY	PART CODE	DESCRIPTION	DIV.
1	EL9020	Cabin Wiring	

FIG. 83 WIRING CHASSIS TO ROOF



KEY	PART CODE	DESCRIPTION	DIV.
1	EL9120	Wiring Chassis to Roof	

FIG. 83A WIRING DOOR FRAME RIGHT TO ROOF




KEY	PART CODE	DESCRIPTION	DIV
1	EL9122	Wiring Chassis to Roof	

FIG. 84 PTO VALVE



KEY	PART CODE	DESCRIPTION	DIV.
1	EL9065	Wiring PTO-valve	

FIG. 85 ENGINE WIRING




KEY	PART CODE	DESCRIPTION	DIV.
1	EL9031	Engine Wiring 2030	
2	EL9029	Engine Wiring 2040	

FIG. 86 BATTERY PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	EL1055	Battery	
2	EL8564	Fuse Bracket	
3	EL8560	Fuse Socket	
4	EL8555	40 Amp Fuse	
5	EL8562	Cover	

FIG. 87 CHASSIS EL PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	EL2015	Rear Light Left + Right	
2	EL9050	Wiring Right Rear Light	
3	EL9055	Wiring Left Rear Light	
4	EL2544	Trailer Connector	
5	EL9215	Distributing Wiring	
6	EL9210	Wiring Trailer Connector	
7	EL2412	Reverse alarm	
8	EL2413	Wiring Reverse alarm	




FIG. 88 CHASSIS EL PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	EL2012	Work Lamp	
2	EL2015	Rear Light Left + Right	
3	EL2010	Front Lamp	
4	ST3074	Consol	
5	EL2018	Blink lamp	
6	EL2012	Work Lamp	
7	EL1015	Option	
8	EL2022	Mounting set flashing beacon	
9	EL2020	Flashing beacon	

FIG. 89 CHASSIS EL PARTS




KEY	PART CODE	DESCRIPTION	DIV.
1	EL9222	Headlight Right	
2	EL9220	Headlight Left	
3	EL2000	Working light Front	
4	EL2005	Working light Rear	
5	EL2015	Taillight	
6	EL2021	Socket for Beacon flasher	
7	EL2020	Beacon flasher	
8	EL9223	Headlight rubber	

FIG. 90 WIRING CHASSIS




KEY	PART CODE	DESCRIPTION	DIV.
1	EL9015A	Wiring Chassis	

FIG. 91 CONNECTORS AND TOOLS




KEY	PART CODE	DESCRIPTION	DIV.
1	VÆ7010	Cast Tool Set for Multi Connectors (14, 15)	
2	VÆ7010	Cast Tool	
3	EL4010	Relay Standard	
4	EL4020	Micro-Relay	
5	EL4022	Socket for Micro-relay	
6	EL8110	Socket for relay Standard	
7	EL1119	Connector for SWF Switches	
8	EL8190	Connector Generator	
9	EL8165	6 Pin Super seal Male	
9A	EL8167	6 Pin Super seal Female	
10	EL8160	3 Pin Super seal Male	
10A	EL8161	3 Pin Super seal Female	
11	EL8158	2 Pin Super seal Male	
11A	EL8159	2 Pin Super seal Female	
12	EL8182	Pins super seal Female	
13	EL8180	Pins super seal Male	
14	EL3514	Multi Connector Female 19 + 20 Pin ITT-Canon	

FIG. 92 CONNECTORS AND TOOLS




KEY	PART CODE	DESCRIPTION	DIV.
14A	EL3512	Multi Connector Male 19+20Pin ITT-Canon	
15	EL3507	Multi Connector Female 19 Pin ITT-Canon	
15A	EL3505	Multi Connector Male 19 Pin ITT-Canon	
16	EL3525	Pin Signal for ITT-Canon Male Connector	
16A	EL3527	Pin Signal for ITT-Canon Female Connector	
17	EL3530	Pin Power for ITT-Canon Male Connector	
17A	EL3532	Pin Power for ITT-Canon Female Connector	
18	EL3555	UMNL Connector 12 Pin Male	
18A	EL3550	UMNL Connector 12 Pin female	
19	EL3547	UMNL Connector 6 Pin Male	
19A	EL3541	UMNL Connector 6 Pin Female	
20	EL3540	UMNL Connector 9 Pin Male	
20A	EL3542	UMNL Connector 9 Pin Female	
21	EL3546	UMNL Connector 4 Pin Male	
21A	EL3540	UMNL Connector 4 Pin Male	
22	EL3557	Pin For All UMNL Male Connectors	
23	EL3556	Pin For All Female UMNL Connectors	

FIG. 93 CONNECTORS AND TOOLS



KEY	PART CODE	DESCRIPTION	DIV.
24	EL8136	Multi Connector 4 Pin Male	
24A	EL8134	Multi Connector 4 Pin Female	
25	EL8122	Multi Connector 2 Pin Male	
25A	EL8120	Multi Connector 2 Pin Female	
26	EL8130	Multi Connector 3 Pin Male	
26A	EL8128	Multi Connector 3 Pin Female	
27	EL8115	Cover Female Pins	
27A	EL8117	Cover Male Pins	
28	EL3126	Male Pins	
29	EL3110	Female Pins	

FIG. 94 HAND BRAKE PARTS



KEY	PART CODE	DESCRIPTION	DIV.
1	EL4050	Brake Light Switch	
2	BM3003	Screw	
3	BM2515	Washer 4 mm	
4	BM2000	Nut 4 mm	
5	EL9100	Connector	
6	ST3390	Spacer	
7	BM2615	Washer 6 mm	
8	BM2010	Nut 6 mm	
9	BM5050	Bolt	
10	ST3268	Bracket	

FIG. 95 HYD. HOSE LISTING 2030 **Used to frame No. 113**

1/4" HYD HOSE LISTING 2030 (1. lags Min: 250 bar.) Used to frame No. 113						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL1010	Manoeuvring Valve lift	90*	Lift cyl.	90*	290	1
HYDSL1014	Manoeuvring Valve sec 2	90*	Quick release left	90*	900	2
HYDSL1018	Steering cylinder	90*	Orbitrol	90*	550	1
HYDSL1022	Steering cylinder	90*	Orbitrol	90*	750	1
HYDSL1026	Manoeuvring Valve option	90*	Throttle	Straight	1980	1
HYDSL1030	Lift cylinder option	90*	Throttle	Straight	1700	1
HYDSL1034	3. Section tee up	90*	Quick couplings Front Right	90*	900	1

3/8" HYD HOSE LISTING 2030 (1. lags Min: 250 bar.) Used to frame No. 113						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL1510	Manoeuver valve port P	45*	Rear pump	90*	135	1
HYDSL1514	Pump on the engine	90*	Orbitrol port P	90*	180	1
HYDSL1518	HST buster outlet	90*	From orbitrol port P	90*	180	1
HYDSL1522	Manoeuver valve 3	90*	Top couplings Rear	Straight	175	1
HYDSL1524	Manoeuver valve 3	90*	Top couplings Rear	Straight	171	1
HYDSL1526	Wheel motor rear L	90*	Wheel motor rear R	90*	900	1

1/2" HYD HOSE LISTING 2030 (2. lags Min: 300 bar.) Used to frame No. 113						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL2006	Wheel motor front	90*	Tee front	Straight	180	2
HYDSL2010	Wheel motor front	90*	Tee Rear	Straight	980	2
HYDSL2014	Tee drain Rear	90*	Wheel motor rear	90*	270	1
HYDSL2018	Tee drain Rear	90*	Wheel motor rear	90*	220	1
HYDSL2022	Tee drain Rear	Straight*	Wheel motor rear	90*	170	2
HYDSL2024	PTO valve T side	90*	Couplings Rear top	45*	1950	1
HYDSL2026	Return Block Rear 1 Layer	90*	Return Block Rear 1 Layer	90*	380	1
HYDSL2030	Return Block Rear	90*	Return Block Rear	90*	380	1
HYDSL2034	PTO valve T-port	Straight*	Return Block Rear	Straight	750	1

3/4" HYD HOSE LISTING 2030 (2. lags Min: 300 bar.) Used to frame No. 113						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL2510	HST port A	90*	Tee between front wheel motors	Straight	800	1
HYDSL2514	HST port B	90*	Tee between rear wheel motors	Straight	120	1
HYDSL2518	PTO valve port P	90*	PTO valve port P	90*	900	1
HYDSL2522	PTO valve port A	Straight	Quick release bottom	90*	350	1
HYDSL2526	PTO valve port B	Straight	Quick release top	90*	400	1

FIG. 96 HYD. HOSE LISTING 2040 **Used to frame No. 113**

¼" HYD HOSE LISTING 2040 (1. lags Min: 250 bar.) Used to frame No. 113						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL5010	Wheel motor front L drain	Straight	Tee manoeuvring valve	Straight	290	1
HYDSL5015	Wheel motor front R drain	90*	Tee manoeuvring valve	Straight	290	1
HYDSL5020	Lift cylinder rear end	90*	Manoeuvring valve sec. 1	90*	300	1
HYDSL5025	Wheel motor rear R drain	Straight	Return Block Rear	90*	1400	1
HYDSL5030	Wheel motor rear L drain	90*	Return Block Rear	90*	340	1
HYDSL5035	Manoeuvre valve sec. 2 and 3	90*	Quick couplings Front	90*	900	4
HYDSL5040	Steering cylinder	90*	Orbitrol	90*	560	1
HYDSL5045	Steering cylinder	90*	Orbitrol	90*	770	1
HYDSL5050	Manoeuvre valve sec. 1	90*	Throttle valve cabin	Straight	1700	1
HYDSL5055	Throttle valve cabin	90*	Lift cylinder rear	Straight	1980	1

¾" HYD HOSE LISTING 2040 (1. lags Min: 250 bar.) Used to frame No. 113						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL5310	Manoeuver valve s. 3 Tee	90*	Couplings Rear	Straight	175	1
HYDSL5315	Manoeuver valve s. 3 Tee	90*	Couplings Rear	Straight	171	1
HYDSL5320	Twin pump	90*	Manoeuver valve port P	45*	135	1
HYDSL5325	Pump on the engine	90*	Orbitrol port P	90*	180	1
HYDSL5330	Orbitrol port T	90*	HST buster outlet	90*	180	1
HYDSL1526	Wheel motor L	90*	Wheel motor R	90*	900	1

½" HYD HOSE LISTING 2040 (2. lags Min: 300 bar.) Used to frame No. 113						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL5410	Wheel motor front	90*	Tee front	Straight	85	2
HYDSL5415	Wheel motor front	90*	Wheel motor rear	Straight	1400	2
HYDSL5420	Wheel motor rear	Straight	HST port B	45*	270	1
HYDSL5425	Wheel motor rear	Straight	HST port B	45*	260	1
HYDSL5430	Tee PTO valve port A	90*	Couplings Rear	45*	1950	1

½" HYD HOSE LISTING 2040 (1. lags Min: 100 bar.) Used to frame No. 113						
HYDSL5450	Return Block Rear	90*	Couplings Rear	90*	380	2
HYDSL2034	PTO valve port T	Straight	Quick couplings Front	Straight	750	1

¾" HYD HOSE LISTING 2040 (2. lags Min: 300 bar.) Used to frame No. 113						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL5510	HST port A	Straight	Tee between front wheel motors	45*	680	1
HYDSL5515	PTO pump port P	90*	PTO valve port P	45*	1600	1
HYDSL5520	PTO valve port A	Straight	Quick release bottom	90*	350	1
HYDSL5525	PTO valve port B	Straight	Quick release top	90*	400	1

FIG. 97 HYD. HOSE LISTING 2030 **Used from frame No. 114**

¼" HYD HOSE LISTING 2030 (1. lags Min: 250 bar.) Used from frame No. 114						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL1010	Manoeuvring Valve lift	90*	Lift cyl.	90*	290	1
HYDSL1015	Manoeuvring Valve sec 2	90*	Quick release left	Straight	880	1
HYDSL1016	Manoeuvring Valve sec 2	90*	Quick release left	Straight	900	1
HYDSL1019	Steering cylinder	90*	Orbitrol	90*	1200	1
HYDSL1023	Steering cylinder	90*	Orbitrol	90*	1150	1
HYDSL1026	Lift cyl.	90*	Throttle	Straight	1980	1
HYDSL1030	Manoeuvring Valve sec 1	90*	Throttle	Straight	1700	1
HYDSL1035	Manoeuver valve 3	45*	Quick release front	Straight	670	1
HYDSL1036	Manoeuver valve 3	45*	Quick release front	Straight	690	1

¾" HYD HOSE LISTING 2030 (1. lags Min: 250 bar.) Used from frame No. 114						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL1510	Manoeuver valve port P	45*	Rear pump	90*	135	1
HYDSL1514	Pump on the engine	90*	Orbitrol port P	90*	180	1
HYDSL1518	HST buster outlet	90*	From orbitrol port P	90*	180	1
HYDSL1522	Manoeuver valve 3	90*	Top couplings Rear	Straight	175	1
HYDSL1524	Manoeuver valve 3	90*	Top couplings Rear	Straight	171	1
HYDSL1526	Wheel motor rear L	90*	Wheel motor rear R	90*	900	1

½" HYD HOSE LISTING 2030 (2. lags Min: 300 bar.) Used from frame No. 114						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL2006	Wheel motor front	90*	Tee front	Straight	180	2
HYDSL2010	Wheel motor front	90*	Tee Rear	Straight	980	2
HYDSL2014	Tee drain Rear	90*	Wheel motor rear	90*	270	1
HYDSL2018	Tee drain Rear	90*	Wheel motor rear	90*	220	1
HYDSL2022	Tee drain Rear	Straight*	Wheel motor rear	90*	170	2
HYDSL2024	PTO valve T side	90*	Couplings Rear top	45*	1950	1
HYDSL2026	Return Block Rear 1 Layer	90*	Return Block Rear 1 Layer	90*	380	1
HYDSL2030	Return Block Rear	90*	Return Block Rear	90*	380	1
HYDSL2035	PTO valve T-port	Straight*	Quick release	Straight	530	1

¾" HYD HOSE LISTING 2030 (2. lags Min: 300 bar.) Used from frame No. 114						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL2510	HST port A	90*	Tee between front wheel motors	Straight	800	1
HYDSL2514	HST port B	90*	Tee between rear wheel motors	Straight	120	1
HYDSL2518	PTO valve port P	90*	PTO valve port P	90*	900	1
HYDSL2522	PTO valve port A	Straight	Quick release bottom	90*	350	1
HYDSL2526	PTO valve port B	Straight	Quick release top	90*	400	1

FIG. 98 HYD. HOSE LISTING 2040 **Used from frame No. 114**

¼" HYD HOSE LISTING 2040 (1. lags Min: 250 bar.) Used from frame No. 114						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL5010	Wheel motor front L drain	Straight	Tee manoeuvring valve	Straight	290	1
HYDSL5015	Wheel motor front R drain	90*	Tee manoeuvring valve	90*	290	1
HYDSL5020	Lift cylinder rear end	90*	Manoeuvring valve sec. 1	90*	300	1
HYDSL5025	Wheel motor rear R drain	Straight	Return Block Rear	90*	1400	1
HYDSL5030	Wheel motor rear L drain	90*	Return Block Rear	90*	340	1
HYDSL5036	Manoeuvre valve sec. 2	90*	Quick couplings Front	Straight	880	1
HYDSL5037	Manoeuvre valve sec. 2	90*	Quick couplings Front	Straight	900	1
HYDSL5042	Steering cylinder	90*	Orbitrol	90*	1150	1
HYDSL5047	Steering cylinder	90*	Orbitrol	90*	1200	1
HYDSL5050	Manoeuvre valve sec. 1	90*	Throttle valve cabin	Straight	1700	1
HYDSL5055	Throttle valve cabin	Straight	Lift cylinder rear	90*	1980	1
HYDSL5038	Manoeuvre valve sec. 3	90*	Quick couplings Front	Straight	670	1
HYDSL5039	Manoeuvre valve sec. 2	90*	Quick couplings Front	Straight	690	1

¾" HYD HOSE LISTING 2040 (1. lags Min: 250 bar.) Used from frame No. 114						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL5310	Manoeuver valve s. 3 Tee	90*	Couplings Rear	Straight	1750	1
HYDSL5315	Manoeuver valve s. 3 Tee	90*	Couplings Rear	Straight	1710	1
HYDSL5320	Twin pump	90*	Manoeuver valve port P	45*	1350	1
HYDSL5325	Pump on the engine	90*	Orbitrol port P	90*	1800	1
HYDSL5330	Orbitrol port T	90*	HST buster outlet	90*	1800	1
HYDSL1526	Wheel motor L	90*	Wheel motor R	90*	900	1

½" HYD HOSE LISTING 2040 (2. lags Min: 300 bar.) Used from frame No. 114						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL5410	Wheel motor front	90*	Tee front	Straight	85	2
HYDSL5415	Wheel motor front	90*	Wheel motor rear	Straight	1140	2
HYDSL5420	Wheel motor rear	Straight	HST port B	45*	270	1
HYDSL5425	Wheel motor rear	Straight	HST port B	45*	260	1
HYDSL5430	Tee PTO valve port A	90*	Couplings Rear	45*	1950	1

½" HYD HOSE LISTING 2040 (1. lags Min: 100 bar.) Used from frame No. 114						
HYDSL5450	Return Block Rear	90*	Couplings Rear	90*	380	2
HYDSL2035	PTO valve port T	Straight	Couplings Front	Straight	530	1

¾" HYD HOSE LISTING 2040 (2. lags Min: 300 bar.) Used from frame No. 114						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL5510	HST port A	Straight	Tee between front wheel motors	45*	700	1
HYDSL5515	PTO pump port P	90*	PTO valve port P	90*	1600	1
HYDSL5520	PTO valve port A	Straight	Quick release bottom	90*	350	1
HYDSL5525	PTO valve port B	Straight	Quick release top	90*	400	1

FIG. 99 HYD. HOSE LISTING JOYSTICK 2030/40 **Used from frame No. 114**

1/4" HYD HOSE LISTING 2030/40 JOYSTICK (2. lags Min: 200 bar.) Used from frame No. 114						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL6520	Flow valve	90*	Manoeuvring valve	Straight	700	1
HYDSL6525	Float Valve	90*	Lift cylinder	90*	290	1
HYDSL6530	Throttle valve cabin	Straight	Flow valve	90*	1540	1
HYDSL6535	Throttle valve cabin	Straight	Manoeuvring valve	90*	1660	1
HYDSL6540	Manoeuvring valve	90*	Lift cylinder	90*	400	1

3/8" HYD HOSE LISTING 2030/40 JOYSTICK (1. lags Min: 200 bar.) Used from frame No. 114						
Parts no.	Position From	Fittings	Position To	Fittings	L. mm	Pcs
HYDSL6560	Flow valve	90*	Pump on the motor chamber	90*	1350	1
HYDSL6565	Overcurrent block	90*	Throttle valve cabin	Straight	2140	1
HYDSL6570	Overcurrent block	Straight	PTO block T-stk.	Straight	270	1
HYDSL6575	Overcurrent block	Straight	Manoeuvring valve	Straight	220	1
HYDSL6580	Throttle valve cabin	45*	Manoeuvring valve	Straight	1740	1
HYDSL6585	Throttle valve cabin	Straight	Quick couplings Front	45*	1390	1
HYDSL1670	Motor function front	Straight	Motor function back	45*	2650	1

Part code	Page	Part code	Page
AC2510	50	BM2620	73
AC2511	50	BM2635	84
AC2526	64	BM2650	27
AC2530	65	BM2795	77
AC2531	65	BM2805	36
AC2532	65	BM2805	41
AC2537	64	BM3002	52
AC2538	65	BM3003	102
AC2541	65	BM3015	53
AC2542	65	BM3015	78
AC3020	65	BM3110	78
AC5020	64	BM3505	63
AC5022	64	BM3505	77
AC8040	64	BM3530	66
AC8041	64	BM5050	102
AC8042	65	BM5120	49
AC8043	65	BM5255	17
AC8046	65	BM5260	12
AC8047	65	BM5390	42
AC8046	50	BM5420	36
AC8047	50	BM5425	61
BM1110	35	BM5490	19
BM1118	35	BM5520	39
BM1334	48	BM5655	48
BM1570	19	BM6030	29
BM1788	30	BM8210	78
BM1838	84	BM9210	63
BM1870	27	BM9210	64
BM2000	102	BM9215	21
BM2001	52	BM9220	21
BM2010	102	BM9220	43
BM2011	63	BM9220	44
BM2020	35	BM9230	45
BM2020	73	BM9230	46
BM2020	78	BM9260	48
BM2021	61	BR1015	12
BM2041	12	BR1020	12
BM2051	84	DIV1025	73
BM2070	27	DIV1027	73
BM2340	11	DIV1030	73
BM2340	49	DIV1034	74
BM2350	30	DIV1036	74
BM2415	61	DIV1038	74
BM2445	12	DIV1040	74
BM2515	52	DIV1042	73
BM2515	102	DIV1044	74
BM2531	73	DIV10502	69
BM2547	84	DIV10503	70
BM2615	63	DIV10504	68
BM2615	102	DIV1051	72
BM2620	61	DIV1051A	72

Part code	Page	Part code	Page
DIV1052A	71	DIV5010	86
DIV1054	75	DIV5035	86
DIV1055	75	DIV5036	86
DIV1080	83	DIV5037	86
DIV1085	83	DIV5050	39
DIV1525	53	DIV5050	86
DIV1550	66	DIV5110	24
DIV2009	64	DIV5110	79
DIV2012	63	DIV5112	24
DIV2035	63	DIV5112	79
DIV2035	64	DIV6010	13
DIV2036	63	DIV6014	13
DIV2036	64	DIV6014	53
DIV2040	66	DIV6018	13
DIV2050	67	DIV6020	13
DIV2070	67	DIV6030	13
DIV2072	9	DIV8010	56
DIV2072	67	DIV8021	56
DIV2128	39	DIV8021	62
DIV2130	67	DIV8030	39
DIV2310	56	DIV8033	39
DIV2312	56	EL1010	52
DIV2320	56	EL1015	96
DIV2330	56	EL1018	52
DIV2332	56	EL1031	52
DIV2335	57	EL1055	94
DIV2340	56	EL1105	24
DIV2342	56	EL1115	52
DIV2345	56	EL1119	99
DIV2350	56	EL1120	24
DIV2360	56	EL1157	52
DIV2380	56	EL1170	24
DIV2385	56	EL1170	52
DIV2390	56	EL1185	52
DIV3058	52	EL1230	81
DIV3070	52	EL2000	97
DIV4105	81	EL2005	97
DIV4109	82	EL2010	96
DIV4116	10	EL2012	96
DIV4116	82	EL2015	95
DIV4121	10	EL2015	96
DIV4121	15	EL2015	97
DIV4125	10	EL2016A	39
DIV4125	15	EL2018	96
DIV4131	10	EL2020	96
DIV4133	10	EL2020	97
DIV4135	10	EL2021	97
DIV4135	11	EL2022	96
DIV4135	84	EL2250	24
DIV4138	12	EL2254	24
DIV4327	15	EL2517	34

Part code	Page	Part code	Page
EL2520	51	EL8560	94
EL2540	55	EL8562	94
EL2544	95	EL8564	94
EL3110	101	EL8980	94
EL3126	101	EL9005	87
EL3505	100	EL9015A	98
EL3512	100	EL90181A	24
EL3514	99	EL9020	90
EL3514	100	EL9029	93
EL3525	100	EL9031	93
EL3527	100	EL9050	95
EL3530	100	EL9055	95
EL3532	100	EL9065	92
EL3540	100	EL9100	102
EL3541	100	EL9110	89
EL3542	100	EL9112	88
EL3546	100	EL9115	88
EL3547	100	EL9116	88
EL3550	100	EL9120	91
EL3555	100	EL9122	95
EL3556	100	EL9125	53
EL3557	100	EL9152	51
EL4010	52	EL9200	52
EL4010	99	EL9210	95
EL4014	55	EL9215	95
EL4020	99	EL9220	97
EL4022	99	EL9222	97
EL4050	15	EL9223	97
EL4050	102	FI1350	21
EL4100	81	FI1410	21
EL8110	99	FI1418	21
EL8115	101	FS6710	37
EL8117	101	FS6712	37
EL8120	101	GF1210	39
EL8122	101	GF1212	39
EL8128	101	GF1213	39
EL8130	101	GF1216	39
EL8134	101	GF1217	39
EL8136	101	GF1217A	39
EL8158	99	GF2020	85
EL8159	99	GF2025	85
EL8160	99	GL1010	58
EL8161	99	GL1014	58
EL8165	99	GL1028	60
EL8167	99	GL1035	60
EL8180	99	GL1510	58
EL8182	99	GL1514	58
EL8190	50	GL1518	59
EL8190	99	GL1524	59
EL8510	52	GL1528	60
EL8555	94	GL1535	60

Part code	Page	Part code	Page
GL2010	61	HYD1563	19
GL2020	57	HYD1564	19
GL2020	61	HYD1705	15
GL2025	56	HYD1715	16
GL8010	61	HYD1717	16
GU1009	81	HYD1720	11
GU1012	77	HYD1722	11
GU1026	63	HYD1724	11
GU1026	76	HYD1760	17
GU1026	77	HYD1804	19
GU1027	63	HYD1806	19
GU1027	76	HYD1807	19
GU1040	41	HYD1910	20
GU1040	61	HYD1912	9
GU1116	77	HYD1912	20
GU1210	61	HYD1915	20
GU2110	63	HYD1916	9
GU2110	64	HYD1917	20
GU2114	43	HYD1925	20
GU2114	44	HYD1927	9
GU3010	84	HYD1950	20
GU3013	30	HYD2308	18
GU3013A	38	HYD2315	18
GU3015	84	HYD2315A	18
GU4010	36	HYD2317	25
GU4560	26	HYD2317A	25
GU4562	26	HYD2317B	25
GU4564	26	HYD2322	25
GU4570	26	HYD2325	18
GU4624	20	HYD2325	25
GU5020	65	HYD2330	25
GU5024	30	HYD3107	22
GU5110	25	HYD3108	22
GU5150	76	HYD3109	22
GU5150	77	HYD3114	22
GU6012	57	HYD3115	22
GU6027	65	HYD3122	22
GU6070	63	HYD3124	22
GU6070	65	HYD3124	23
GU6070	77	HYD3130	23
GU6072	63	HYD3135	23
GU6072	77	HYD3165	23
GU6640	37	HYD3166	23
HJ1020	14	HYD3170	23
HJ1040	14	HYD3171	23
HJ2010	14	HYD3178	23
HJ5010	11	HYD3180	23
HJ5010	14	HYD3181	23
HJ5145	12	HYD4001	26
HYD1551	18	HYD4004	26
HYD1558	19	HYD4010	26

Part code	Page	Part code	Page
HYD4014	26	HYDSL2006	103
HYD4018	26	HYDSL2006	105
HYD4019	26	HYDSL2010	103
HYD4735	16	HYDSL2010	105
HYD4745	17	HYDSL2014	103
HYD4746	17	HYDSL2014	105
HYD4912	41	HYDSL2018	103
HYD4914	41	HYDSL2018	105
HYD4947	41	HYDSL2022	103
HYD5054	26	HYDSL2022	105
HYD5058	26	HYDSL2024	103
HYD5060	26	HYDSL2024	105
HYD5102	63	HYDSL2026	103
HYD5102	64	HYDSL2026	105
HYD5314	26	HYDSL2030	103
HYD5318	26	HYDSL2030	105
HYD5320	26	HYDSL2034	103
HYD7069	21	HYDSL2034	104
HYD7070	21	HYDSL2035	105
HYD7120	21	HYDSL2035	106
HYDSL1010	103	HYDSL2510	103
HYDSL1010	105	HYDSL2510	105
HYDSL1014	103	HYDSL2514	103
HYDSL1015	105	HYDSL2514	105
HYDSL1016	105	HYDSL2518	103
HYDSL1018	103	HYDSL2518	105
HYDSL1019	105	HYDSL2522	103
HYDSL1022	103	HYDSL2522	105
HYDSL1023	105	HYDSL2526	103
HYDSL1026	103	HYDSL2526	105
HYDSL1026	105	HYDSL5010	104
HYDSL1030	103	HYDSL5010	106
HYDSL1030	105	HYDSL5015	104
HYDSL1034	103	HYDSL5015	106
HYDSL1035	105	HYDSL5020	104
HYDSL1036	105	HYDSL5020	106
HYDSL1510	103	HYDSL5025	104
HYDSL1510	105	HYDSL5025	106
HYDSL1514	103	HYDSL5030	104
HYDSL1514	105	HYDSL5030	106
HYDSL1518	103	HYDSL5035	104
HYDSL1518	105	HYDSL5036	106
HYDSL1522	103	HYDSL5037	106
HYDSL1522	105	HYDSL5038	106
HYDSL1524	103	HYDSL5039	106
HYDSL1524	105	HYDSL5040	104
HYDSL1526	103	HYDSL5042	106
HYDSL1526	104	HYDSL5045	104
HYDSL1526	105	HYDSL5047	106
HYDSL1526	106	HYDSL5050	104
HYDSL1670	107	HYDSL5050	106

Part code	Page	Part code	Page
HYDSL5055	104	KØ9010	41
HYDSL5055	106	LS12112	80
HYDSL5310	104	LS12115	80
HYDSL5310	106	LS9503	24
HYDSL5315	104	LS9503	79
HYDSL5315	106	LS9507	79
HYDSL5320	104	LS9804	78
HYDSL5320	106	LS9808	78
HYDSL5325	104	LS9813	73
HYDSL5325	106	LS9839	63
HYDSL5330	104	LSRF20603	63
HYDSL5330	106	LSRF20604	79
HYDSL5410	104	LSRF20605	79
HYDSL5410	106	LSRF20606	79
HYDSL5415	104	MOT1019	50
HYDSL5415	106	MOT1060	43
HYDSL5420	104	MOT1069A	43
HYDSL5420	106	MOT1089	43
HYDSL5425	104	MOT2047	45
HYDSL5425	106	MOT8300	47
HYDSL5430	104	MOT8300	48
HYDSL5430	106	MOT9000	49
HYDSL5450	104	MOT9001	49
HYDSL5450	106	MOT9102	46
HYDSL5510	104	MOT9103	9
HYDSL5510	106	MOT9103	46
HYDSL5515	104	MOT9104	46
HYDSL5515	106	MOT9105	9
HYDSL5520	104	MOT9105	45
HYDSL5520	106	MOT9106A	45
HYDSL5525	104	MOT9107	45
HYDSL5525	106	MOTC1520	9
HYDSL6520	107	MOTC1525	9
HYDSL6525	107	MOTC1530	9
HYDSL6530	107	MOTC2010	50
HYDSL6535	107	MOTC2012	50
HYDSL6540	107	MOTC2013	50
HYDSL6560	107	MOTC2015	9
HYDSL6565	107	MOTC2015	44
HYDSL6570	107	MOTC2015	50
HYDSL6575	107	MOTC2020	9
HYDSL6580	107	MOTC2020	50
HYDSL6585	107	MOTC4950	50
HYP2020	19	MOTC4955	50
HYP2030	19	MOTC4970	46
KI4015	27	MOTC5012	47
KØ1035	40	MOTC5013	47
KØ1062	41	MOTC5014	48
KØ1210	42	MOTC5015	47
KØ2020	41	MOTC5015	48
KØ4120	43	MOTC5017	47

Part code	Page	Part code	Page
MOTC5017	48	ST2540	46
MOTC5018	48	ST2550	38
MOTC5020	47	ST2555	42
MOTC6014	43	ST2577	50
MOTC6014	44		
MOTC6011	44		
MOTC6013	43		
MOTC6013	43		
MOTC6014	44		
MOTC6015	43		
MOTC6025	43		
MOTC6030	44		
RAT1025	51		
RAT3005	51		
RAT3006	51		
RAT3010	55		
RAT3015	54		
RAT3017	54		
RAT3020	55		
RAT3022	54		
RAT3040	55		
RAT3042	55		
RAT3044	55		
RAT3046	55		
RAT3050	54		
RAT3052	54		
RAT3056	54		
RAT3058	54		
RAT3060	54		
RAT3064	54		
RAT3065	54		
RAT3066	54		
RAT3067	54		
RAT3070	54		
ST1078	18		
ST1086	80		
ST1087	80		
ST1111	29		
ST1112	29		
ST1116	29		
ST1117	29		
ST1125	29		
ST1130	29		
ST1135	29		
ST1510	27		
ST2510	42		
ST2512	15		
ST2513	15		
ST2515	15		
ST2515	50		
ST2541	45		

Part code	Page	Part code	Page
ST2710	76		
ST2780	81		
ST3018	35		
ST3022	35		
ST3023	35		
ST3024	32		
ST3025	32		
ST3026A	29		
ST3030	20		
ST3031B	38		
ST3031AA	20		
ST3032A	34		
ST3032A	38		
ST3034	31		
ST3036	31		
ST3037	31		
ST304005	30		
ST304012	30		
ST3041A	30		
ST3041B	30		
ST3042	18		
ST3049A	30		
ST3051A	82		
ST3059	28		
ST3060	28		
ST30651	42		
ST3070	33		
ST3074	96		
ST30911	83		
ST30914	76		
ST30914	77		
ST3095	76		
ST3095A	77		
ST3096	80		
ST3098	56		
ST3107	37		
ST3111	37		
ST3114	37		
ST3122	37		
ST3123	37		

Specifications subject to change.

We reserve the right to make changes to the machine without at the same time these instructions are change.



Producent:
Lindholdt Maskiner A/S
6818 Årre DK.